Service Manual Notebook Computer

CF-18



This is the Service Manual for the following areas. M ...for U.S.A. and Canada

Model No. CF-18NHHZXBM

🖄 WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.



© 2006 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.

WARNING

For U.K.

This apparatus must be earthed for your safety.

To ensure safe operation the three-pin plug must be inserted only into a standard three-pin power point which is effectively earthed through the normal household wiring.

Extension cords used with the equipment must be three-core and be correctly wired to provide connection to earth. Wrongly wired extension cords are a major cause of fatalities.

The fact that the equipment operates satisfactorily does not imply that the power point is earthed and that the installation is completely safe.

For your safety, if you have any doubt about the effective earthing of the power point, consult a qualified electrician.

FOR YOUR SAFETY PLEASE READ THE FOLLOWING TEXT CAREFULLY

This appliance is supplied with a moulded three pin mains plug for your safety and convenience. A 3 amp fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 3 amps and that it is approved by ASTA or BSI to BS 1362.

Check for the ASTA mark $\widehat{\heartsuit}$ or the BSI mark $\widehat{\heartsuit}$ on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced. If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13 AMP SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician. Warning: THIS APPLIANCE MUST BE EARTHED.

Important

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow:	Earth
Blue:	Neutral
Brown:	Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured GREEN-and-YELLOW must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol () coloured GREEN or GREEN-and-YELLOW.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured BLACK.

The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured RED.

The mains plug on this equipment must be used to disconnect the mains power. Please ensure that a socket outlet is available near the equipment and shall be easily accessible.

How to replace the fuse

Open the fuse compartment with a screwdriver and replace the fuse.



Warnings

• This equipment is not designed for connection to an IT power system.

(An IT system is a system having no direct connections between live parts and Earth; the exposed-conduciveparts of the electrical installation are earthed.

An IT system is not permitted where the computer is directly connected to public supply systems in the U.K.)

• Disconnect the mains plug from the supply socket when the computer is not in use.

This equipment is produced to BS800/1983.

LASER SAFETY INFORMATION

For U.S.A.

Class 1 LASER-Product

This product is certified to comply with DHHS Rules 21 CFR Subchapter J. This product complies with European Standard EN60825 (or IEC Publication 825)

For all areas

This equipment is classified as a class 1 level LASER product and there is no hazardous LASER radiation.

Caution:

- (1) Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- (2) The drive is designed to be incorporated into a computer-based system or unit which has an enclosing cover. It should never be used as a stand alone drive.

Danger:

The serviceman should not remove the cover of drive unit and should not service because the drive unit is a nonserviceable part.

Please check DANGER label on PD-drive unit.

• Unplug the AC power cord to the equipment before opening the top cover of the drive.

When the power switch it on, do not place your eyes close to the front panel door to look into the interior of the unit.

LASER Specification

Class 1 level LASER Product Wave Length: DVD 658±8 nm CD 775~815 nm

Laser safety information is appropriate only when drive with laser is installed.

Safety precautions

- 1. Before servicing, unplug the power cord to prevent an electric shock.
- 2. When replacing parts, use only manufacture's recommended components for safety.
- 3. Check the condition of the power cord. Replace if wear or damage is evident.
- 4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.

Important Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- 1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- 2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- 4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

- LITHIUM BATTERY 🖄 -

· CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the equipment manufacture. Discard used batteries according to the manufacturer's instructions.

- LITHIUMBATTERIES 🖄 -

Vorsicht!

Explosionsgefahr bei unsachgemäßem Austausch der Batterie. Ersatz nur durch denselben order einen vom Hersteller empfohlenen ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

- PILE AU LITHIUM 🖄 –

ATTENTION: IL Y A DANGER D'EXPLOSION S' IL Y A REMPLACEMENT INCORRECT DE LA PILE. REMPLACER UNIQUEMENT AVEC UNE PILE DU MÈME TYPE OU D'UN TYPE RECOMMANDÉ PAR LE CONSTRUCTEUR. METTRE AU RÉBUT LES PILES USAGÉES CONFORMÉMENT AUX INSTRUCTIONS DU FABRICANT.

For U.S.A. / CANADA



A lithium ion battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.

L'appareil que vous vous êtes procuré est alimenté par une batterie au lithium-ion. Pour des renseignements sur le recyclage de la batterie, veuillez composer le 1-800-8-BATTERY.

Lithium Battery

Lithium Battery!

This computer contains a lithium battery to enable the date, time, and other data to be stored. The battery should only be exchanged by authorized service personnel.

Warning! A risk of explosion from incorrect installation or misapplication may possibly occur.

Precautions (Battery Pack)

• Care should be exercised with regard to the following in order to avoid the possibility of overheating, fire or damage.



Avoid Heat

Do not throw the battery pack into a fire or expose it to excessive heat.



Keep Articles Away

Do not place the battery pack together with articles such as necklaces or hairpins when carrying or storing.



Do Not Disassemble

Do not insert sharp objects into the battery pack, expose it to bumps or shocks, deform, disassemble, or modify it.



Do Not Short

Do not short the positive (+) and negative (-) contacts.



Avoid Extreme Heat, Cold and Direct Sunlight

Do not charge, use or leave the battery pack for extended periods where it will be exposed to direct sunlight, in a hot place (in an automobile on a sunny day, for example), or in a cold place.



Do Not Use With Any Other Computer

The battery pack is rechargeable and was intended for the specified computer or charger. Do not use it with a computer other than the one for which it was designed.



Do Not Put into a Microwave

Do not put the battery pack into a microwave oven or a pressurized chamber.



Discontinue Use

Should the battery emit an abnormal odor, become hot to the touch, become discolored, change shape, or become in any way different from normal, remove it from the computer or charger and discontinue use.

- Do not touch the terminals on the battery pack. The battery pack may no longer function properly if the contacts are dirty or damaged.
- Do not expose the battery pack to water, or allow it to become wet.

- If the battery pack will not be used for a long period of time (a month or more), charge or discharge (use) the battery pack until the remaining battery level becomes 30% to 40% and store it in a cool, dry place.
- This computer prevents overcharging of the battery by recharging only when the remaining power is less than approx. 95% of capacity.
- The battery pack is not charged when the computer is first purchased. Be sure to charge it before using it for the first time. When the AC adaptor is connected to the computer, charging begins automatically.
- Should the battery leak and the fluid get into your eyes, do not rub your eyes. Immediately flush your eyes with clear water and see a doctor for medical treatment as soon as possible.

NOTE

- The battery pack may become warm during recharging or normal use. This is completely normal.
- Recharging will not commence outside of the allowable temperature range (0 °C to 50 °C {32°F to 122 °F}).(Reference "Battery Power") Once the allowable range requirement is satisfied, charging begins automatically. Note that the recharging time varies based on the usage conditions. (Recharging takes longer than usual when the temperature is 10 °C {50 °F} or less.)
- If the temperature is low, the operating time is shortened. Only use the computer within the allowable temperature range.
- The battery pack is a consumable item. If the amount of time the computer can be run off a particular battery pack becomes dramatically shorter and repeated rechargings do not restore its performance, the battery pack should be replaced with a new one.
- When transporting spare batteries inside a package, briefcase, etc., it is recommended that it be placed in a plastic bag so that its contacts are protected.
- Always power off the computer when it is not in use. Leaving the computer on when the AC adaptor is not connected will exhaust the remaining battery capacity.

CONTENTS

1 Diagnosis Procedure	·1-1
2 Power-On Self Test (Boot Check)	·2-1
3 List of Error Codes	·3-1
4 Diagnostic Test	·4-1
5 Self Diagnosis Test	·5-1
6 Wiring Connection Diagram	·6-1
7 Disassembly/Reassembly	·7-1
3 Exploded View	·8-1
9 Replacement Parts List	·9-1

1 Diagnosis Procedure

1.1. Basic Procedure

The basic procedures for diagnosis, disassembly, and test of defective parts of a set to be repaired are summarized below. For details, refer to relevant pages in the Service Manual.

• Flow Chart



1.2. Troubleshooting

Please take note of the following two points with regard to troubleshooting:

- 1. Know-how of diagnosis upon occurrence of heavy troubles, e.g. 'Set cannot be turned ON', 'Set fails to start', 'No display on screen', etc.
- 2. Explanation of each trouble, mainly symptom of trouble in operation.



2 Power-On Self Test (Boot Check)

Outline of POST

The set has a boot check function called POST (Power-On Self Test) in it. The condition of the main body is diagnosed by checking beep sound or error code.

- StartTest begins automatically when power switch is set to ON.
- Normal finishAfter memory checking, a beep sound is issued once and the set is placed into automatic stop.

Note: If no error occurs, nothing is displayed. (No display of OK, etc.)

Error Diagnosis by Checking Beep Signal Sound

The beep sound is as follows:



(Length of bar shows length of sound.)

= long sound (about 0.4 sec.), = short sound (about 0.2 sec.), Length between sounds is about 0.1 sec.

• Table of errors classified by beep sounds

Diagnosis	Beep signal sound	Error message	
Main board	1(long sound)-2	BIOS ROM error	
	1-2-2-3	BIOS ROM error	
	1-3-1-1	RAM error	
	1-3-1-3	Keyboard controller error	
	1-3-4-1	RAM error	
	1-3-4-3	RAM error	
1-4-1-1RAM error2-1-2-3BIOS ROM error		RAM error	
		BIOS ROM error	
	2-2-3-1	Occurrence of unexpected offering	

(Note) A beep sound is also issued in case of other I/O trouble.

3. List of Error Codes < Only when the port replicator is connected>

The following is a list of the messages that BIOS can display. Most of them occur during POST. Some of them display information about a hardware device, e.g., the amount of memory installed. Others may indicate a problem with a device, such as the way it has been configured. Following the list are explanations of the messages and remedies for reported problems.

If your system displays one of except the messages marked below with an asterisk (*), write down the message and contact Panasonic Technical Support. If your system fails after you make changes in the Setup menus, reset the computer, enter Setup and install Setup defaults or correct the error.

0200 Failure Fixed Disk

Fixed disk in not working or not configured properly. Check to see if fixed disk is attached properly. Run Setup. Find out if the fixed-disk type is correctly identified.

0210 Stuck key

Stuck key on keyboard.

0211 Keyboard error

- Keyboard not working.
- 0212 Keyboard Controller Failed

Keyboard controller failed test. May require replacing keyboard controller.

0213 Keyboard locked - Unlock key switch

Unlock the system to proceed.

0230 System RAM Failed at offset: nnnn

System RAM failed at offset nnnn of in the 64k block at which the error was detected.

0231 Shadow RAM Failed at offset: nnnn

Shadow RAM failed at offset nnnn of the 64k block at which the error was detected.

0232 Extended RAM Failed at offset: nnnn

Extended memory not working or not configured properly at offset *nnnn*.

0250 System battery is dead - Replace and run SETUP

The CMOS clock battery indicator shows the battery is dead. Replace the battery and run Setup to reconfigure the system.

*0251 System CMOS checksum bad - Default configuration used

System CMOS has been corrupted or modified incorrectly, perhaps by an application program that changes data stored in CMOS. The BIOS installed Default SETUP Values. If you do not want these values, enter Setup and enter your own values. If the error persists, check the system battery or contact Panasonic Technical Support.

0260 System timer error

The timer test failed. Requires repair of system board.

0270 Real time clock error

Real-time clock fails BIOS test. May require board repair.

*0280 Previous boot incomplete - Default configuration used

Previous POST did not complete successfully. POST loads default values and offers to run Setup. If the failure was caused by incorrect values and they are not corrected, the next boot will likely fail. On systems with control of **wait states**, improper Setup settings can also terminate POST and cause this error on the next boot. Run Setup and verify that the wait-state configuration is correct. This error is cleared the next time the system is booted.

0281 Memory Size found by POST differed from EISA CMOS

Memory size found by POST differed from EISA CMOS.

02D0 System cache error - Cache disabled

Contact Panasonic Technical Support.

02F0: CPU ID:

CPU socket number for Multi-Processor error.

02F4: EISA CMOS not writable

ServerBIOS2 test error: Cannot write to EISA CMOS.

02F5: DMA Test Failed

ServerBIOS2 test error: Cannot write to extended DMA (Direct Memory Access) registers.

02F6: Software NMI Failed

ServerBIOS2 test error: Cannot generate software NMI (Non-Maskable Interrupt).

02F7: Fail - Safe Timer NMI Failed

ServerBIOS2 test error: Fail-Safe Timer takes too long.

device address Conflict

Address conflict for specified device.

Allocation Error for: *device*

Run ISA or EISA Configuration Utility to resolve resource conflict for the specified device.

Failing Bits: nnnn

The hex number *nnnn* is a map of the bits at the RAM address which failed the memory test. Each 1 (one) in the map indicates a failed bit. See error 230,231 or 232 for offset address of the failure in System, Extended or Shadow memory.

Invalid System Configuration Data

Problem with NVRAM (CMOS) data.

I/O device IRQ conflict

I/O device IRQ conflict error.

Operating System not found

Operating system cannot be located on either drive A: or drive C: Enter Setup and see if fixed disk and drive A: are properly identified.

Parity Check 1 nnnn

Parity error found in the system bus. BIOS attempts to locate the address and display it on the screen. If it cannot locate the address, it displays ????. Parity is a method for checking errors in binary data. A parity error indicates that some data has been corrupted.

Parity Check 2 nnnn

Parity error found in the I/O bus. BIOS attempts to locate the address and display it on the screen. If it cannot locate the address, it displays ????.

Press <F1> to resume, <F2> to Setup

Displayed after any recoverable error message. Press $\langle F1 \rangle$ to start the boot process or $\langle F2 \rangle$ to enter a Setup and change the settings. Write down and follow the information shown on the screen.

4. Diagnostic Test

4.1 Equipment

(1) Test Computer	1 unit
(2) External Floppy Disk Drive	1 unit
(3) AC Adapter	1 pc.
(4) Loopback Plug (Serial Port Test for RS232C) [P/N: DFWV95C0067]	1 pc.
(5) Floppy Disk containg file DIAG	1 pc.

4.2 Preparation

- (1) Connect the AC Adapter and External Equipments.
- (2) The System Setup should be set to the factory setting values by executing the "SETUP UTILITY" which can be invoked by F2 key at the POST. If not, the messages and items of the diagnostic test may not be displayed properly on the LCD.
- (3) The serial port must be enabled in the "SETUP UTILITY" in order to execute the "1st SERIAL PORT" test.
- (4) Connect the serial loopback plug.

5 Self Diagnosis Test

Floppy disk is Included for the self-diagnostic tests that should be performed before using this product. Important notice

1. System password

If the password function has been turned on, you will need to ask the user for the password before performing the self-diagnostics.

2. FDD test

Performing the FDD test will erase the contents of the floppy disk you insert into the drive. Use a formatted disk that has no contents or whose contents are not required. This product has a password function. However, if this function is turned on, the self-diagnostics tests will not work.

5.1. Outline of Self Diagnostic Tests



to error messages that occur during testing.

5.1.1 List of main test items

The Selection item displays the items selected under Automatic test. If you select Automatic test, these test items will be performed automatically. You can use Selection test to choose items from the menu screen that you want to have tested.

These items are shown below.

1		SPEAKER TEST	Speaker test	0
2		VESA MODE TEST	VESA mode test	0
3	CPU	A20 GATE TEST	Address A20 line	0
4	(CPU related)	CACHE ON/OFF TEST	Cache memory on/off test	0
5		NPU OPERAND TEST	Floating point processor function test	0
6	RAM (Memory related)	RAM STANDARD TEST	Memory standard test	0
7	CONTROL	DMA PAGE REG TEST	DMA page register test	0
8	(Control ICs on the main	DMA REGISTER TEST	DAM register test	
9	board, etc.)	DMAC TRANSFER TEST	DAM transfer test	0
10		PIC HALT INSTRUCTION TEST	Interrupt controller halt instruction test	0
11		PIC REGISTER TEST	Interrupt controller register test	0
12		RTC CMOS RAM TEST	Real time clock CMOS test	0
13		RTC TEST	Real time clock test	0
14		PIT CH0 TEST	interrupt timer CH0	0
15		PIT CH1 TEST	interrupt timer CH1	0
16		PIT CH2 TEST	interrupt timer CH2	0
17	10	KEYBOARD REG TEST	Keyboard test	0
18	(Input-output)	PS/2 MOUSE REG	Mouse registration test	0
19	COMMUNICATION	SERIAL WRAP TEST	Serial loop back (jig required)	—
20		SERIAL ALL INTERNAL TEST	Serial port interior test	0
21		PARALLEL REGISTER R/W	Parallel register R/W test	0
22	AUX	PCIC ALL TEST	PCIC test	0
23	(Auxiliary functions)	Card Bus Reg	Card Bus register test	0
24		USB Reg	USB register test	0
25	VIDEO	VGA ALL TEST	VGA test	0
26	(Display related)	SVGA RAM TEST	SVGA RAM test	0
27	DISK	FD WT/RD/WP TEST	FD WT, RD WP test	
28	(FDD, HDD)	HDD ALL TEST	Only HDD lead test selected	0
29	UNIQUE	ECP REGISTER R/W	ECP register R/W test	0
30	(Individual functions)	EPP REGISTER R/W	EPP register R/W test	0
31		EXT. CMOS R/W TEST	Extension CMOS R/W test	0
		• · · · · · · · · · · · · · · · · · · ·		

Test function settings	Test condition save/play	Following file command
	Test automatic execute	Test executed on run settings by selecting command
	Error display (Paging style)	Select displayed items Error, Log, Option

5.2. Automatic Test

Test execution

From the menu screen shown below For Celeron models Select and press Enter for DIAG on FD

1. DIAG on FD (CF-18 XP/2000 Model)
2. DIAG on FD (CF-18 Tablet Model)
3. LAN Test
4. Modem Test
5. Wireless LAN test (Wireless LAN Model only)
6. Button Test
Q. Quit
Select please [1, 2, 3, 4, 5, 6, Q] ?

menu screen

Speaker test, VESA test

The speaker test involves listening to music and choosing OK or Not okay. The VESA test involves looking at the display to see if it is satisfactory then choosing OK or Not okay.

Serial loop back test

The Automatic test's initial settings are set so that the serial loop back test will be executed. Connect the serial loop back jig and then perform the test. (This test is not executed on default mode)

Diagnostics result

If no errors occur. The screen shows the word "Pass" in large letters. If errors occur. The test is stopped when an error occurs and the error message is displayed. For explanations of error messages, see Error Messages and Problem Categories (section 5.5).

Quitting the test

At the screen shown below, simultaneously press the ALT and X keys.

Eile Sel	oot Duo	Error	00	Option	Nincow.
The per	act nen		LUS	UPCION	WIECOW
Alt-X Exit	Alt-F4	4 Close	F I Ú	Manu	



5.3. Peripheral Test

Test execution

From the menu screen shown below, be sure to choose the following items and press Enter.

1. DIAG on FD (CF-18 XP/2000 Model)
2. DIAG on FD (CF-18 Tablet Model)
3. LAN Test
4. Modem Test
5. Wireless LAN test (Wireless LAN Model only)
6. Button Test
Q. Quit
Select please [1, 2, 3, 4, 5, 6, Q] ?

menu screen

3. LAN Test

4. Modem Test

5. Wireless LAN Test

(Wireless LAN Model only.) This test checks for internal LAN device. Choose LAN test and press Enter.

5.4. Test Selection

Starting up the input menu

1. From the menu screen shown below, choose Quit and press Enter.

1. DIAG on FD (CF-18 XP/2000 Model) 2. DIAG on FD (CF-18 Tablet Model)
3. LAN Test
4. Modem Test
5. Wireless LAN test (Wireless LAN Model only)
6. Button Test
Q. Quit
Select please [1, 2, 3, 4, 5, 6, Q] ?

menu screen

2. When A: \DIAG appears, input "JDG_185" and press Enter.

 The input screen shown below will appear. To choose menu items, hold down "ALT" and press the selection key.

Example: "AL T" + "F" brings up the File menu.



5.5. Error Messages and Troubleshooting

The table below explains the parts that may be faulty or damaged should an error message occur while performing the various test items of the self diagnostics program.

	Test classification	Screen display test items	Contents
1	CPU	A20 GATE TEST	Address 20 line
2	(CPU related)	CACHE ON/OFF	Cache memory on/off
3		NPU OPERAND TEST	Floating point processor function
4	RAM (Memory related)	RAM STANDARD	Memory standard
5	CONTROL	DMA PAGE REG TEST	DMA page register
6	(Control ICs on the	DMA REGISTER TEST	DAM register
7	main board, etc.)	DMAC Transfer TEST	DAM transfer test
8]	PIC HALT INSTRUCTION TEST	Interrupt controller
9		PIC REGISTER TEST	Interrupt controller
10		RTC CMOS RAM TEST	Real time clock CMOS
11			
12		SPEAKER TEST	Speaker
13		PIT CH0 TEST	Interrupt timer CH0
14		PIT CH1 TEST	Interrupt timer CH1
15		PIT CH2 TEST	Interrupt timer CH2
16	10	KEYBOARD REG TEST	Keyboard
17	(Input-output)	PS/2 MOUSE REG	Mouse
18	COMMUNICATION	SERIAL WRAP TEST	Serial loop back (jig required)
19		SERIAL ALL INTERNAL TEST	Serial port
20		PARALLEL REGISTER R/W	Parallel register
	AUX	PCIC ALL TEST	PCIC
21	(Auxiliary functions)	Card Bus REG	Card Bus port
		USB REG	USB port
22	VIDEO	VGA ALL TEST	VGA
23	(Display related)	SVGA RAM TEST	SVGA RAM
24		VESA MODE TEST	VESA mode
25	DISK	FD WT/RD/WP TEST	FD write/read/write protection
26	(FDD, HDD)	HDD ALL TEST	Only HDD lead selected
27	UNIQUE	ECP REGISTER R/W	Parallel port
28	(Individual functions)	EPP REGISTER R/W	Parallel port
29]	EXT. CMOS R/W TEST	Extension CMOS R/W test

6 Wiring Connection Diagram



7 Disassembly/Reassembly

Note:

Power off the computer. Do not shut down to the Suspend or hibernation mode. Do not add peripherals while the computer is in the Suspend or hibernation mode; abnormal operation may result.

7.1. Disassembly Instructions

7.1.1. Preparation

Before disassembling, be sure to make the following preparations.

- Shut down Windows and turn off the power.
- Disconnect the AC adaptor.
- Remove the optional DIMM memory card and PCMCIA card if they are connected.
- Remove other devices if they are connected.

Attention:

- Please execute writing BIOS ID when you exchange the Main Board.
- Parts (Sheet and rubber) etc. related various the Conductive Cloth and Heat Spreader cannot be recycled. Use new parts.

7.1.2. Removing the Battery Pack and HDD Pack



- 1. Open the Battery Cover.
- 2. Remove the Battery Pack.
- 3. Open the HDD Cover.

4. Remove the HDD Pack.



- 5. Remove the two Screws <A>.
- 6. Remove the HDD Case A and the HDD Case B.
- 7. Remove the HDD.

Screws <A>:DFHE5025XA

7.1.3. Removing the Touch Pad and Keyboard



1. Remove the Palm Rest Ass'y.

Note: The Palm Rest Ass'y is firmly fixed with two-sided tape.

Carefully remove the Palm Top Cover Sheet not to damage it.

2. Remove the four Screws .

3. Remove the KBD Plate.



4. Lift the far side of the Keyboard and slide it to backward, and then turn the Keyboard over frontward.



- 5. Remove the three Screws <C>.
- 6. Remove the KBD Connector Cover.



- 7. Disconnect the Cable from Connector (CN18).
- 8. Remove the Keyboard.

9. Remove the TP Tape.

- 10. Disconnect the Cable from Connector (CN800).
- 11. Remove the Touch Pad and Click Button Plate.

Screws :DRSB2+5FKL Screws <C>:DFHE5025XA

7.1.4. Removing the Speaker Angle and DIMM Lid



- 1. Remove the four Screws <D>.
- 2. Disconnect the Cable from Connector (CN37).
- 3. Remove the DIMM Lid.
- 4. Remove the two Screws <E>.
- 5. Remove the Speaker Angle.

Screws <D>: DRQT2+D2FKL Screws <E>: DRHM5025YA

7.1.5. Removing the Rear Cabinet



- 1. Remove the thirteen Screws <F>.
- 2. Open the LID Rubbers.
- 3. Remove the Rear Cabinet.

Screws <F>:DRHM0061ZA

7.1.6. Removing the DU Lid Unit



1. Remove the five Screws <G>.

2. Remove the DU Lid Angle and DU Lid.

Screws <G>:DRHM5025YA

7.1.7. Removing the Audio PCB



- 1. Remove the two Screws <H>.
- 2. Disconnect the Cable from a Connector (CN901).
- 3. Remove the Audio PCB.

Screws <H>:DRSB2+5FKL

7.1.8. Removing the Wireless Module, Port PCB and Modem



Note:

This procedure is not necessary if the computer is not equipped with Wireless Module or Modem PCB.

- 1. Disconnect the two Antenna Cables from two Connectors (J5, J6).
- 2. Remove the Wireless Module.
- 3. Remove the three Screws <I>.
- 4. Remove the Port PCB.
- 5. Remove the two Screws <J>.
- 6. Remove the Modem.
- 7. Disconnect the Modem cable from the connector.
- 8. Remove the two Screws <K>.
- 9. Remove the BAT CON angle.

Screws <I>:DRSB2+5FKL Screws <J>:XSB2+4FNL Screws <K>:DRSB2+5FKL

7.1.9. Removing the SD PCB



- 1. Disconnect the Cable from Connector(CN21).
- 2. Remove the three Screws <h>
- 3. Remove the SD PCB.

Screws <h>:DXQN2+A22FNL

7.1.10. Removing the Main PCB and Lithium Battery



- 1. Disconnect the Cable from Connector(CN3).
- 2. Remove the Lithium Battery.
- 3. Disconnect the seven Cables from seven Connectors (CN9, CN12, CN14, CN23, CN30, CN35, CN36).
- 4. Remove the Screw <L>.
- 5. Remove the two Screws <M>.
- Disconnect the two Cables from two Connectors (CN8, CN17).
- 7. Remove the four Screws <N>.
- 8. Remove the Main PCB.
- 9. Remove the PCMCIA Unit.

Screw <L>:DRSB2+5FKL Screws <M>:DXYN2+J12FNL Screws <N>:DXYN2+J18FNL

7.1.11. Removing the PAD PCB and I/O PCB



- 1. Disconnect the Cable from Connector (CN801).
- 2. Remove the three Screws <O>.
- 3. Remove the PAD PCB.
- 4. Remove the four Screws <P>.

- 5. Remove the two Screws <Q>.
- 6. Remove the I/O PCB.

Screws <O>:DFHE5025XA Screws <P>:DFHE5058ZB Screws <Q>:DRSB2+5FKL

7.1.12. Removing LED PCB and Switch PCB



- 1. Remove the LED Waterproof Sheet.
- 2. Remove the LED PCB.
- 3. Remove the Switch PCB.
- 4. Remove the Power Switch.

7.1.13. Removing the CPU Heat Plate



- 1. Remove the three Screws <R>.
- 2. Remove the CPU Heat Plate.

Screws <R>:DFHE5025XA

7.1.14. Removing the Display unit



- 1. Remove the four Screws <S>.
- 2. Remove the LCD Hinge Cover.



- 3. Display unit is half-rotated and removes the two Screws <T>.
- 4. Remove the four Screws <U>.



5. Turn the computer over.
6. Remove the Display Unit.

Screws <S> : DFHE5025XA Screws <T> : DRSB2+5FKL Screws <U> : DXYN4+J8FNL

7.1.15. Removing the LCD Rear Case



- 1. Remove the eight Screws <V> on the front side of Display unit.
- 2. Remove the eight Screws <V> on the back side of Display unit.
- 3. Remove Antenna Cover and Tablet Latch Cover.
- 4. Remove the two Screws <W>.
- 5. Remove the ten Screws <X>.
- 6. Remove the LCD Rear Case.

Screws <V> : DRQT26+E5FKL Screws <W> : DXYN3+J10FNL Screws <X> : DXYN2+J6FNL

7.1.16. Removing the LCD Hinge



- 1. Remove the Cable Holder.
- 2. Remove the two Screws <Y>.
- 3. Remove the Cable Holder Plate and LCD Hinge.

Screws <Y> : DXYN3+J8FNL

7.1.17. Removing Inverter PCB and LCD 7.1.19. Removing the Each Cover Unit



- 1. Disconnect the two Cables from two Connectors (CN1, CN2).
- 2. Remove the Inverter Case and Inverter PCB.
- 3. Disconnect the two Cable from two connector (CN900, CN901).
- 4. Remove the TS PS2 PCB, then remove the LCD unit.
- 7.1.18. Removing GPRS Antenna PCB, LAN1-BT PCB, LAN2-BT PCB, Wide Area Aux PCBand Pen Holder



- 1. Remove the two Screws <a>.
- 2. Remove the GPRS Antenna PCB
- 3. Remove the two Screws <a>.
- 4. Remove the LAN1-BT PCB.
- 5. Remove the two Screws <a>.
- 6. Remove the LAN2-BT PCB.
- 7. Remove the two Screws <a>.
- 8. Remove the Wide Area Aux PCB.
- 9. Remove the Pen
- 10. Remove the two Screws .
- 11. Remove the Pen Holder.

Screws <a> : DFHE5025XA Screws : DRHM5025YA



PCMCIA LID ASS'Y

- 1. Remove the 12 Screws <f>.
- 2. Remove the Moden/LAN LID Rubber, LAN LID Rubber, USB LID Rubber, DC IN LID Rubber, Serial LID Rubber, RGB LID Rubber and Audio LID Rubber.
- 3. Remove the Rear Cabinet. (Refer to 7.1.5 Removing the Rear Cabinet)
- 4. Remove the six Screws <e>.
- 5. Remove the Battery LID ASS'Y, HDD LID ASS'Y and PCMCIA LID ASS'Y.

Screws <e>:DRQT26+D3FKL Screws <f>:DRHM5025YA

7.2. Reassembly Instructions

7.2.1. Attention when CF-18 series is repaired

- Please execute writing BIOS ID when you exchange the Main Board.
- Parts (Sheet and rubber) etc. related various the Conductive Cloth and Heat Spreader cannot be recycled. Use new parts.

7.2.2. Setting up the LCD UNIT

- 1. Set the LCD UNIT to the LCD FRONT CABINET/TS PANEL.
- 2. Fix the LCD Back Damper using the 2 Screws. <Z>
- 3. Set the TS PS2 PCB on the LCD Back Damper, and connect the 2 Cables to the Connectors (CN900 and CN901).
- 4. Set the INVERTER PCB to the LCD Back Damper, and connect the 2 Cables to the Connectors (CN1 and CN2).

Screws <Z> :DXHM0042ZA



Assembly of LCD Back Damper (Applicable Model : Touch Screen Model)



Assembly of LCD Back Damper (Applicable Model : Digitizer Model)



Assembly of Inverter PCB (Applicable Model : Touch Screen Model)





Assembly of Touch Screen (Applicable Model : Touch Screen Model)



Assembly of Glass (Applicable Model : Digitizer Model)





7-11

7.2.4. Setting up the LCD Hinge

- 1. Wind the Cable coming out of the LCD Unit conterclockwise to the LCD Hinge.
- 2. Set the Lock Plate and the Hinge Top Cover, and rotate the LCD Hinge to turn the Display Unit to front
- 3. Put the LCD Cable and the Antenna Cable in the Cable Holder.
- 4. Fit another Cable Holder and clamp the Cable Holders in the LCD Hinge.
- 5. Fix the LCD Hinge using the 2 Screws <Y> and the 2 Cable Holder Plates.

Screws <Y> : DXYN3+J8FNL



Assembly of LCD Hinge



Line processing of Antenna Cable and LCD Cable



7.2.5. Assembling the Anntena Cover, the Tablet Latch Cover and the LCD Rear Case

- 1. Fix the LCD Rear Case using the 10 Screws <X> and the 2 Screws <W>.
- 2. Attach the Antenna Covers and the Tablet Latch Cover to the Display Unit.
- 3. Tighten the 8 Screws <V> on the back of the Display Unit.
- 4. Turn the Display Unit over, and tighten the 8 Screws. <V>

Screws <V> : DRQT26+E5FKL Screws <W> : DXYN3+J10FNL Screws <X> : DXYN2+J6FNL





Assembly of LCD Front Case



Assembly of LCD Rear Case (Applicable Model : Touch Screen Model)



Assembly of Tablet Latch Cover and Antenna Cover



7.2.6. Setting the Display Unit

1. Fix the Display Unit using the 2 Screws <T>.



2. Close the Display Unit and turn the computer over, and then fix the Display Unit using the 4 Screws <U>.



Assembly of Display Unit

- 3. Turn the computer over and fix the LCD Hinge Cover using the 2 Screws <S>.
- 4. Open the Display Unit and fix the LCD Hinge Cover using the 2 Screws <S>.

Screws <S> : DFHE5025XA Screws <T> : DRSB2+5FKL Screws <U> : XYN4+J8FNL




7.2.7. Setting the CPU Heat Plate

1. Fix the CPU Heat Plate using the three Screws<R>.

Screws <R>:DFHE5025XA



Line Processing of the Modem Cable, and putting of the Heatsink Rubber.



7.2.8. Setting the LED PCB and the Switch PCB

- 1. Set the Power Switch.
- 2. Set the Switch PCB.
- 3. Set the LED PCB.
- 4. Attach the new LED Waterproof Sheet.



Assembly of the LED PCB and the Switch PCB



7.2.9. Setting the PAD PCB and the I/O PCB

- 1. Fix the I/O PCB using the four Screws<P> and the two Screws<Q>.
- 2. Fix the PAD PCB using the three Screws<O>.
- 3. Connect the SW Cable to the Connector (CN801) of the PAD PCB.

Screws <O>:DFHE5025XA Screws <P>:DFHE5058ZB Screws <Q>:DRSB2+5FKL



Assembly of PAD PCB





Hook on the protrusions of the boss and the Power Switch.

7.2.10. Setting the Main PCB and the Lithium Battery

- 1. Set the PCMCIA Unit to Main PCB
- 2. Mount the HDD Guide Plate and set the Main PCB.
- 3. Fix the Main PCB using the four Screws <N> and the two Screws <M>.
- 4. Fix the Main PCB using the Screw <L>.
- 5. Connect the seven Cables to the corresponding Connectors (CN9,CN12,CN14,CN23,CN30,CN35,CN36).
- 6. Turn the computer over and connect the two Cables to the corresponding Connectors (CN8, CN17).
- 7. Connect the Cable to the Connector (CN3), and fix the Lithium Battery.

Screw <L>:DRSB2+5FKL Screws <M>:DXYN2+J12FNL Screws <N>:DXYN2+J18FNL





Line Processing of the Antenna Cable



Line Processing of the Lithium Battery

Lithum Battery

Connect the Cable to the Connector CN3 of the Board. (Right angle type)



Cushion for Lithum Battery Attach on the IC14 (Super I/O). Attach the white adhesive surface to the IC side.



• After attaching the Cushion for Lithum Battery, set the Lithum Battery as shown below.

Attach the Lithum Battery on the Cushion. Draw the Lead Wire toward the end of the Board. 1 Arrange the surplus length of the Lead Wire as shown below.





7.2.11. Setting the SD PCB

- 1. Fix the SD PCB using the three Screws <h>.
- 2. Connect the Cable to the Connector (CN21).

Screws<h>:DXQN2+A22FNL



<h>

7.2.12. Setting the Wireless Module, the Port PCB, and the Modem

- 1. Fix the Battery Connect Angle using the two Screws <K>.
- 2. Connect the Modem cable to the Connector, and fix the Modem on the Main PCB using the two Screws <J>.
- 3. Fix the Port PCB on the Main PCB using the three Screws <I>.
- 4. Connect the Wireless Module to the Main PCB, and connect the two Antenna Cables (J5, J6) to the Wireless Module.

Screws <I>:DRSB2+5FKL Screws <J>:XSB2+4FNL Screws <K>:DRSB2+5FKL



Assembly of the Port PCB



Line Processing of the Wireless Module,Port PCB and Modem



7.2.13. Setting the Audio PCB

1. Connect the Cable to the Connector of the Audio PCB (CN901), and fix the Audio PCB using the two Screws<H>.

Screws<H>:DRSB2+5FKL



Putting of the Sheet



7.2.14. Assembling the DU Lid Unit

1. Fix the DU Lid Angle and the DU Lid using the five Screws<G>.

Screws <G>:DRHM5025YA



7.2.15. Setting the Rear Cabinet

- 1. Fix the Rear Cabinet on the computer using the 13 Screws <F>. No1 to No13
- 2. Close the LID Rubbers.

Note:

Tighten the Screws in the numbered order (No1 to No13).

Screws<F>:DRHM0061ZA





Cautions for Setting the Rear Cabinet

7.2.16. Setting the Speaker and Dimm Lit

- 1. Fix the Speaker Angle to the DIMM Lit using the two Screws <E>.
- 2. Connect the Speaker Cable to the Connector (CN37) of the Main PCB.
- 3. Fix the DIMM Lit using the four Screws<D>. No1 to No4

Screws<D>:DRQT2+D2FKL Screws<E>:DRHM5025YA



■ Cautions for Setting the DIMM Lit





When removing the Bottom Case Assy, be sure to remove the DIMM Lid Assy.

7.2.17. Setting the Touch Pad and the Keyboard

- 1. Connect the Cable to the Connector (CN800), and attach the Touch Pad to the computer.
- 2. Set the Click Button Plate.
- 3. Attach the new TP Tape over the Touch Pad.
- 4. Attach the Palm Rest Ass'y on the computer.



- 5. Connect the Cable of the Keyboard to the Connector (CN18) on the Main PCB.
- 6. Fix the KBD Connector Cover using the three Screws<C>.



7. Set the Keyboard to the computer.



8. Fix the KBD Plate using the four Screws.

Screws:DRSB2+5FKL Screws<C>:DFHE5025XA



Putting of the Sheet



Cautions for Setting the Keyboard



Putting of the Palm Rest ASSY



7.2.18. Setting the Battery Pack and the HDD Pack

1. Set the HDD in the HDD Case and fix it using the two Screws<A>.

HDD Case B HDD FPC HDD Hooks Heater

2. Open the HDD Cover and set the HDD Pack.

3. Open the Battery Cover and set the Battery.

Screws<A>: DFHE5025XA





Assembly of the HDD ASSY

7.2.19. Assembling the Each Cover

- 1. Fix the Battery LID Ass'y, the HDD LID Ass'y, and the PCMCIA LID Ass'y using the six Screws<e>.
- 2. Set the Rear Cabinet.
- 3. Fix the Modem/LAN LID Rubber, the LAN LID Rubber, the USB LID Rubber, the DC IN LID Rubber, the Serial LID Rubber, the RGB LID Rubber,and the Audio LID Rubber using the 12 Screws<f>. No1 to No12

Note:

Tighten the Screws in the numbered order (No1 to No12).

Screws <e>:DRQT26+D3FKL Screws <f>:DRHM5025YA



8 Exploded View















9 Replacement Parts List

Note: Important Safety Notice

Components identified by \triangle mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

CF-18NHHZXBM

REF.NO. and AREA	PART NO.	DESCRIPTION	Q'TY
Main Block Unit	•	•	
E1	DL3U11471CAA	PCB, MAIN RTI	_ 1
E2	DL3U21471CAA	PCB, AUDIO RTI	_ 1
E3	DL3U31471CAA	PCB, I/O RTI	_ 1
E4	DL3U1B482AAA	PCB, PAD RTI	_ 1
E5	DL3U2B482AAA	PCB, SWITCH RTI	_ 1
E6	DL3U3B482AAA	PCB, LED RTI	_ 1
E11	DL3U4B482AAA	PCB, PORT RT	_ 1
E14	DL3U11490AAA	PCB, WIDE AREA ANTENNA RTI	_ 1
E14-1	DFJS834YA	GPRS CABLE, GRAY	1
E16	DL3U31490AAA	PCB, BT-LAN2 ANTENNA RT	_ 1
E16-1	DFJS837YA	LAN MAIN CABLE, BLACK	1
E16-2	DFJS835YA	BT CABLE, BLUE	1
E17	DL3U41490AAA	PCB, LAN2 ANTENNA RTI	_ 1
E17-1	DFJS836YA	LAN SUB CABLE, WHITE	1
E18	N2EABEC00006	TOUCH PAD	1
E19	DFJS827YA	CABLE, MODEM	1
E20	DFJS828YA	CABLE, LAN	1
E22	DFJK08T024DB	FFC, SW	1
E24	DFJK10T053DB	FFC, LED	1
E25	DFJK12T034DB	FFC, PAD	1
E26	DFJK24T034DB	FFC, IO	1
E27	DFJK40T072CB	FFC, AUDIO	1
E28 🛆	N0GB1J000018	INVERTER	1
E29	DFJS923YA	CABLE, LCD TS	1
E32	N3CABSD00008	HDD	1
E33	DFWV08A0076	LCD UNIT ASS'Y	1
E33-1	DL3DW0180AAA	LCD ASS'Y	1
E33-1-1	A2CA00000056	LCD BACKLIGHT, CCFL	1
E33-1-2	DFHM0290ZA	REFLECTION ANGLE	1
E33-5	DXHM0042ZA	SCREW	4
E33-6	DFHR3C08ZA	LCD BACK DAMPER	1
E33-7	DFHR3B64ZA	LCD SIDE CUSHION A	2
E33-8	DFHR3506YA	LCD SIDE CUSHION C	2
E33-9	DFHR3507YA	LCD SIDE CUSHION D	1
E33-30	DFHR3453YA	LCD BACK CUSHION SIDE	3
E33-31	DFHR3570YA	LCD BACK CUSHION	1
E33-32	DFHR3571YA	LCD BACK CUSHION S	2
E33-33	DFHR3612ZA	LCD PWB SPACER	1
E33-34	DFHR3647YA	SPACER SHEET	2
E33-35	DFHR3648ZA	HOLDER SHEET B	2
E34	N2ABAJ000001	KEYBOARD, US	1
E35	N5HAZ0000013	MDC MODEM	1
E36	N5HZC0000014	WIRELESS LAN MODULE	1
E42	K1YYZZ000058	CARD BUS SOCKET	1
E100	DL3U5B482AAA	PCB, TS PS2 RTI	_ 1
E150	DL3UP1282AAA	PCB, ANTENNA RT	_ 1
E151	DFJS877YA	CABLE, ANTENNA	1

E208	DFJK13T024DB	FFC, PAD	1
E209	DL3U21490AAA	PCB, WIDE AREA AUX ANTENNA RTL	1
E209-1	DFJS977ZA	CABLE, WIDE AREA AUX ANT. BROWN	1
E210	DL3U7B482AAA	PCB, SD RTL	1
Accessories			
A1 \Lambda	CF-AA1623AM6	AC ADAPTOR	1
A2 \Lambda	K2CG3DR00003	AC CABLE	1
A3 \Lambda	DFQX5561YA	MANUAL	1
A4 🔬	CGR-B/6D8A	BATTERY PACK	1
A6	DFJS954ZA	MODEM CABLE	1
A7	DFHS9017ZA	CLOTH ASS'Y	1
A25	DFQC9006ZB-0	SHOULDER BELT ASS'Y	1
A26	DFME0134ZA	TETHER	1
Packing Material	•	• •	
P1	DFPK1147QA	CASE, PACKING	1
P2	DFPE0599ZA	HOLDER	1
P3	DFPE0733YA	ACCESSORIES BOX	1
Mechanical Parts			
K1	DFWV99A0104	HDD MOUNTING KIT	1
K1-1	L9DZAA000004	HEATER	1
K1-2	DFMX0383TA	INSULATION SHEET	3
K1-3	DFHM0280YA	HDD CASE A	1
K1-4	DFHM0313ZA	MDD GUIDE PIN PLATE	1
K1-5	DFHM9007ZA	HDD CASE B	1
K1-6	DFHE5025XA	SCREW	2
K1-7	DFHR3443XA	HDD DAMPER	1
K1-8	DFHR3589ZA	HDD CASE TAB	1
K1-9	DFHR3601ZA	HDD GUIDE PLATE SPACER	1
K1-10	DFHR3627YA	HDD CUSHION SPACER	1
K1-11	DL3UP1279BAA	FPC ASS'Y. HDD	1
K1-12	DFHP7124ZA	ТАРЕ	1
K1-14	DFHR3A10ZA	HDD SPACER C	1
K1-15	DFMX1207ZA	INSULATION SHEET. HDD HEATER	1
K2	DFHE0326XA	GASKET	2
КЗ	DFHE0519XA	GASKET E	1
К4	DFHE0811YA	GASKET	1
К5	DFHE0815ZA	CONDUCTIVE SHEET	1
K6	DFHG1209ZA	RUBBER. FOOT	4
K7	DFHG1630ZA-0	AUDIO LID RUBBER	1
K8	DFHG1632XA-0	DC IN LID RUBBER	1
K9	DFHG1638ZA-0	MODEM/LAN LID RUBBER	1
K10	DFHG1639ZA-0	USB LID RUBBER	2
K11	DFHG1641ZB-0	RGB LID RUBBER	1
K13	DFHG1660ZA-0	LAN LID RUBBER	1
K15	DFHG427YA	ANTENNA CAP	1
K16	DFHM0379ZA	CPU HEAT PLATE	1
K17	DFHM0276SA	DU CNT ANGLE	1
K18	DFHM0282YA	HDD GUIDE PLATE ASM	1
K19	DFHM0284XA	KB CNT LID	1
K20	DFHM0286YB	LID RUBBER PLATE A	1
K21	DFHM0288ZB	LID RUBBER PLATE C	1
K23	DFHM0296XA-0		1
K24	DEHM0302YA-0	KBD PLATE (I.)	1
K25	DFHM0303YA-0	KBD PLATE (R)	1
K26	DEHM0307YA	BAT CON ANGLE	1
K28	DEHM0311ZB	LID RUBBER PLATE B	2
			2

K31	DFHR3262ZA	MODEM TAPE	2
K32	DFHR3301YA	MINI PCI CARD SHEET	1
K33	DFHR3438ZA	CLICK BUTTON SHEET	1
K34	DFHR3808ZA	GPS HOLE SHEET	1
K35	DFHR3445YA	HEAT DISSIPATION RUBBER	2
K36	DFHR3450ZA	KB CNT HOLE CUSHION	1
K37	DFHR3451ZB	KB CNT LID SHEET	1
K38	DFHR3474YA	TP TAPE	1
K39	DFHR3483SA	OPERATION SHEET	1
K40	DFHR3485ZA	OPERATION TAPE	1
K41	DFHR3487ZA	PORTRE SHEET	1
K42	DFHR3510ZA	LED SHEET	1
K43	DFHR3B11YA	SHEET, PCMCIA	1
K44	DFHR3512ZA	LED WATERPROOF SHEET	1
K45	DFHR3513ZA	LED PWB TAPE	1
K47	DFHR3536YA	LED LIGHT GUIDE SHEET	1
K49	DFHR3551YA	COIN BATTERY SHEET	1
K50	DFHR3581YA	KBD WATERPROOF SHEET L	1
K51	DFHR3582ZA	KBD WATERPROOF SHEET R	1
K52	DFHR3583ZA	KBD WATERPROOF SHEET C	1
K53	DFHR3584ZA	PALMREST SHEET R	1
K55	DFHP7106YA	ТАРЕ	4
K56	DFHR3622ZA-0	DU STOPPER	1
K57	DFHR3623ZA	DU STOPPER A	1
K58	DFHR3624ZA	DU STOPPER B	2
K59	DFHR3625ZA	DU STOPPER C	2
K60	DFHR3626ZA	DU STOPPER D	1
K64	DFHR3636ZA	CABLE HOLD SHEET	2
K66	DFHR3642YA	LCD CUSHION SHEET	2
K67	DFHR3643ZA	ТР ВОТТОМ ТАРЕ	1
K71	DFHR3655YA	HDD CASE SPACER	2
K76	DFHR3677ZA	INSULATION SHEET	1
K77	DFHR6044XA	CLICK BUTTON PLATE	1
K78	DFHR6052XB-0	POWER SW KNOB	1
K79	DFHR9081ZA	PEN	1
K80	DFKE9078YA-0	DIMM LID ASSY SD	1
K80-1	L0AA04A00022	SPEAKER UNIT	1
K80-2	DFHM0275ZB	DIMM LID	1
K80-3	DFHM0298YA	SPEAKER ANGLE	1
K80-4	DFHR3439ZA	DIMM LID SHEET	1
K80-5	DFHR3471ZA	SP WATERPROOF SHEET	1
K80-6	DFHR3520ZA	SPEAKER WASHER	1
K80-7	DFHR3535ZA	SPEAKER CABLE TUBE	1
K80-8	DRHM5025YA	SCREW	2
K80-9	DFMX1070ZA	FDD INSULATION SHEET (2)	1
K80-10	DFHM0377YA	DIMM HEAT SINK PLATE	1
K80-13	DFMX1197ZA	SPEAKER INSULATION SHEET	1
K80-14	DFHR3C04ZA	DIMM CARD INSULATION SHEET	1
K80-15	DFHR3C05ZA	DIMM TIP INSULATION SHEET	1
K80-16	DFHR8509ZA	DIMM PLATE SPACER	1
K81	DFKE9065WA-0	PALM REST ASS'Y	1
K82	DFKM9030ZA-0	BOTTOM CASE ASS'Y	1
K82-1	DFHM0277YA	DU LID ANGLE	1
K82-2	DRHM5025YA	SCREW	5
K82-3	DFHR3441ZA	DU LID WATERPROOF SHEET	1
K82-4	DFHR6045ZA	DU LID	1
· ·	I	-	

K83	DFKM9034XA-0	TOP CASE ASS'Y	1
K83-1	DFKE9073YA-0	TABLET LATCH ASS'Y	1
K83-2	DFKE9071ZA-0	BATT LID ASS'Y	1
K83-2-1	DFBH3030ZA	LID HINGE	2
K83-2-2	DRQT26+D3FKL	SCREW	2
K83-2-3	DFHM0310YA	WASHER	2
K83-2-4	DFHM0315YC	LID LATCH PLATE BATT	1
K83-2-5	DFHR3509YA	BAT COVER SHEET	1
K83-2-6	DFKE0799ZA-0	TABLE LATCH KNOB	1
K83-2-7	DFUN0068XA	LID KNOB SPRING	1
K83-2-8	DFUS0292ZB	LID KNOB SPRING PLATE	1
K83-2-9	DRHM5025YA	SCREW	2
K83-2-10	DXQT2+F3FNLT	SCREW	1
K83-3	DFKE9072ZB-0	HDD LID ASS'Y	1
K83-3-1	DFBH3030ZA	LID HINGE	2
K83-3-2	DRQT26+D3FKL	SCREW	2
K83-3-3	DFHM0310YA	WASHER	2
K83-3-4	DFHM0285XC	LID LATCH PLATE	1
K83-3-5	DFHR3508YA-0	HDD COVER SHEET	1
K83-3-6	DFKE0799ZA-0	TABLE LATCH KNOB	1
K83-3-7	DFUN0068XA	LID KNOB SPRING	1
K83-3-8	DFUS0292ZB	LID KNOB SPRING PLATE	1
K83-3-9	DRHM5025YA	SCREW	3
K83-4	DFKE9075XA-0	PCMCIA LID ASS'Y	1
K83-4-1	DFBH3030ZA	LID HINGE	2
K83-4-2	DRQT26+D3FKL	SCREW	2
K83-4-3	DFHM0310YA	WASHER	2
K83-4-4	DFHM0285XC	LID LATCH PLATE	1
K83-4-5	DFHR3588WA-0	PCMCIA COVER SHEET SD	1
K83-4-6	DFKE0799ZA-0	TABLE LATCH KNOB	1
K83-4-7	DFUN0068XA	LID KNOB SPRING	1
K83-4-8	DFUS0292ZB	LID KNOB SPRING PLATE	1
K83-4-9	DRHM5025YA	SCREW	3
K83-5	DRQT26+D3FKL	SCREW	6
K83-6	DXQT3+F4FNLT	SCREW	2
K83-7	DFHR3480ZA	WL DUMMY SHEET	1
K84	DFMX0383TA	INSULATION SHEET	10
K85	DFHR7518ZA	H CABLE SHEET	3
K86	DFUQ0101YA	SW SPRING	1
K87 /	DFGT1054ZA	RATED LABEL	1
K89	DFQT9675ZA	ENERGY STAR LABEL	1
K92	DFQT9948ZA	CENTRINO LABEL	1
K200	DFWV80A0354	LCD FRONT CABINET/TS PANEL ASS'Y	1
K200-1	DEKE9031ZA-0	FRONT CASE ASS'Y	1
K200-1-1	DRHM5025YA	SCREW	2
K200-1-2	DEHG1634YA-0	I CD CABINET CUSHION A	2
K200-1-3	DEHG1635ZA-0		2
K200-1-4	DEHM0319YA	I CD FL F PASS	2
K200-1-5	DEHM0321ZA	D WASHER	2
K200-1-6	DEHM03227A	SPRING WASHER	2
K200-1-7	DEHR3469ZA	PEN ERICTION SHEET	1
K200-1-8	DEHR60517E	PEN HOLDER	1
K200-2	DEHE0805ZA	MAGNET	1
K200-3	DEHP71497A		1
K200-30	DFW//84A0261		1
K200-30-3	DEHR347674		ן ר
1200-00-0		OFROENT	2

K200-30-4	DFHR3477ZA	SPACER B	2
K200-30-30	DFHR3630ZA	TS FPC SPACER	1
K200-30-31	DFHR3674YA	TS TAPE	1
K200-30-35	DL3DV0180AAA	TS PANEL ASS'Y	1
K200-30-35-1	DFHR9071ZA	PROTECTION FILM	1
K201	DFWV80C0497	LCD REAR CABINET ASS'Y	1
K201-1	DFKM9032ZA-0	REAR CASE ASS'Y	1
K201-1-1	DFHR3468ZA-0	PANA BADGE	1
K201-1-2	DFHG1634YA-0	LCD CABINET CUSHION A	2
K201-1-3	DFHG1635ZA-0	LCD CABINET CUSHION B	2
K201-1-4	DFHM0319YA	LCD ELE PASS	2
K201-1-5	DFHM0321ZA	D WASHER	2
K201-1-6	DFHM0322ZA	SPRING WASHER	2
K201-2	DFHR3563YA	LCD REAR CUSHION C	2
K201-3	DFHR3564YA	LCD REAR CUSHION D	1
K201-4	DFHR3565YA	LCD REAR CUSHION E	2
K201-5	DFHR3566YA	LCD REAR CUSHION F	3
K201-6	DFHR3460YA	LCD REAR CUSHION A	2
K201-7	DFHR3461YA	LCD REAR CUSHION B	2
K201-30	DFHR3567YA	LCD REAR CUSHION G	2
K202	DFBH3029VA	LCD HINGE	1
K203	DFHE0814ZA	CONDUCTIVE SHEET	1
K205	DFHM0325ZA	CABLE HOLD PLATE	2
K206	DFHR3432ZA	ANT CABLE CUSHION	3
K207	DFHR3464WA	I CD SIDE CUSHION B TP	2
K208	DFHR3516ZA	PROTECT SHEET_SCREW	1
K209	DEHR3572YA		1
K210	DEHR3573YA	LCD SIDE CUSHION F	2
K211	DFHR3574YA	I CD SIDE CUSHION F	1
K212	DEHR3614ZA		1
K213	DFHR3631YA	INVERTER CASE	1
K214	DFHR3A65ZA	INSULATION SHEET INV CASE	1
K215	DEHR6193YA-1	ANTENNA COVER	2
K216	DFHR6106ZC-1	TABLET LATCH COVER	1
K217	DFHR6081ZA-0		2
K218	DFKF9059YA	LOCK PLATE ASSY	1
K219	DFKE9074ZA-0	HINGE TOP COVER ASSY	1
K220	DFMC0685ZA		1
K222		INSULATION SHEET	4
K223	DEQT6077YA		1
K224		LOCK SPRING	2
K225	DROT26+E5EKI	SCREW	16
K226		SCREW	10
K227		SCREW	2
K228	DXYN3+J8ENI	SCREW	2
K220		SCREW	8
K230	DFHR34727A-0		1
K252	DFMC0808ZA		1
K253	DEMC0816ZA		1
K301		RELEASE LABEL	1
K400			12
K401		SOREW/	10
K402			13
KADA			4
K405		SOREW/	4
K406			16
1/400	UNODZTOFNL	JUNEW	01

K407	DXYN2+J12FNL	SCREW	2
K408	DXYN2+J18FNL	SCREW	3
K409	DRHM0061ZA	SCREW	13
K410	DXYN4+J8FNL	SCREW	4
K414	XSB2+4FNL	SCREW	4
K500	DFHG1633ZB-0	RUBBER, SERIAL LID	1
K501	DFHR3539YA	SHEET, HEAD SET DUMMY	1
K503	DFHR3644ZA	TAPE, SIMM DUMMY	1
K504	DFQT6255ZA	LABEL, W-LAN	1
K505	DFQT6311ZA	LABEL, FCC ID	1
K550	DFHR3488ZA	SHEET, EXT ANTENNA	1
K551	DFHE5108ZA	SCREW	2
K600	DFMY0419ZA	DIMM THERMAL RUBBER	1
K601	DRYN3+J6FKL	SCREW	2
K602	DFHR3809ZB	GPS HOLE SHEET B	1
K604	DFHR3969ZA	PCMCIA SHEET 3	1
K606	DFQC9009ZC-0	STRAP BG ASS'Y	1
K607	DFHR8516ZA	FFC SPACER	1
K608	DFQT9974ZA	WINDOS XP LABEL (FOR NOTE)	1
K620	DFHR3741ZA	FFC CN STOPPER	2
K671	DFHG1790ZA	BAT CUSHION	1
K685	DFMC0848YA	GASKET	1
K686	DFMX1200ZA	INS. SHEET, TOUCH PAD CARD	1
K687	DFMY0248YA	CPU HEATSINK RUBBER	1
K688	DFHM0378ZA	SD ANGLE	1
K689	DXQN2+A22FNL	SCREW	3
K690	DXSN2+18FNL	SCREW	1
K693	DFHR3859ZA	DC IN SHEET	1
K695	DFHR3B12ZA	SHEET, SD BOARD	1
K696	DFHR3B65ZA	CUSHION, HDD PACK	2
K697	DFHR3B84YA	SPACER, SD ANGLE (1)	1
K698	DFHR3B85ZA	SPACER, SD ANGLE (2)	2
K699	DFHR3B87ZA	SHEET, SD FFC	1
K702	DFHR8517ZA	CUSHION, HDD	2
K703	DFHE0915ZA	SHEET	1
K704	DFHR3C06ZA	INVERTER SHEET (1)	1
K705	DFHR3C07ZA	INVERTER SHEET (2)	1
K708	DFMD3125ZA	BACK PLATE, KENSINGTON 2	1
K709	DFHP7200ZA	TAPE, AHDESIVE	1
K718	DFHR6220ZA	DIMM HOLDER	1

Replacement Parts List

Note: Important Safety Notice

Components identified by \triangle mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.

			DESCRIPTION	
		PART NU.	DESCRIPTION	QIT
	~	0000000510		1
ВП	2:2	CR2032/S5W		76
C 2		F 1JUJ 100AU 10	CAPACITOR, 0.3V, TOUP	70
C 4				
C 6				
C 7				
C 8				
C 11				
C 12				
C 13				
C 15				
C 16				
C 17				
C 19				
C 20				
C 21				
C 23				
C 24				
C 25				
C 26				
C 29				
C 30				
C 31				
C 32				
C 34				
C 35				
C 36				
C 37				
C 40				
C 41				
C 42				
0 43				
0.45				
C 40				
C 48				
C 49				
C 54				
C 62				
C 63				
C 64				

C 70			
C 77			
C 85			
C 86			
C 96			
C 90			
C 90			
0,400			
C 102			
C 103			
C 107			
C 165			
C 170			
C 176			
C 177			
C 180			
C 252			
C 253			
C 278			
C 287			
C 290			
C 303			
C 304			
C 314			
C 316			
C 328			
C 329			
C 335			
C 341			
C 343			
C 348			
C 352			
C 353			
C 369			
C 392			
C 396			
C 692			
<u> </u>	FFFCD0D151FR	CAPACITOR 2V 150UE	4
C 208			
C 214			
C 688			
C 9	F1G1C104A042	CAPACITOR, 16V, 0,1µF	159
C 10			
C 14			
C 18			
C 22			
C 27			
C 33			
C 38			
C 39			
C 44			
	I	•	1 1

C 60			
C 61			
C 65			
C 67			
C 68			
C 69			
C 74			
C 75			
C 76			
C 78			
C 79			
C 82			
C 88			
C 97			
C 100			
C 106			
C 109			
C 111			
C 112			
C 115			
C 116			
C 117			
C 118			
C 121			
C 122			
C 123			
C 124			
C 127			
C 128			
C 130			
C 131			
C 134			
C 135			
C 140			
C 148			
C 149			
C 150			
C 151			
C 156			
C 157			
C 158			
C 159			
C 160			
C 161			
C 162			
C 163			
C 167			
C 191			
C 192			
C 193			
	1	· · ·	I

C 196			
C 198			
C 199			
C 202			
C 203			
C 206			
C 207			
C 209			
C 210			
C 211			
C 213			
C 216			
C 217			
C 218			
C 219			
C 224			
C 225			
C 226			
C 227			
C 228			
C 229			
C 230			
C 231			
C 232			
C 233			
C 235			
C 237			
C 238			
C 242			
C 243			
C 247			
C 254			
C 255			
C 256			
C 261			
C 262			
C 263			
C 264			
C 266			
C 267			
C 268			
C 274			
C 276			
C 280			
C 282			
C 284			
C 285			
C 286			
C 288			
C 289			
	I	1 I	

C 50	F1G1E103A062	CAPACITOR, 25V, 0.01µF	28
C 636			
C 635			
0 629			
C 601			
C 435			
C 434			
C 433			
0 432			
0 430			
C 400			
C 399			
C 395			
0 394			
C 393			
C 391			
C 389			
0 388			
0 384			
0 383			
0 382			
0 377			
0 368			
0 367			
C 366			
C 365			
C 364			
0 363			
C 362			
C 361			
C 354			
C 351			
0 350			
0 349			
0 340			
C 345			
0 330			
0 326			
0 322			
0 321			
C 318			
C 315			
C 313			
C 312			
C 311			
C 293			
C 292			
C 291			

C 166			
C 168			
C 169			
C 171			
C 174			
C 175			
C 178			
C 179			
C 197			
C 215			
C 234			
C 245			
C 246			
C 265			
C 269			
C 270			
C 271			
C 296			
C 299			
C 307			
C 309			
C 347			
C 375			
C 600			
C 628			
C 630			
C 689			
C 55	F1G1H222A496	CAPACITOR, 50V, 2200pF	1
C 56	F1G1A104A014	CAPACITOR, 10V, 0.1µF	7
C 57			
C 187			
C 330			
C 331			
C 332			
C 333			
C 66	F1H0J1050022	CAPACITOR, 6.3V, 1µF	13
C 84			
C 108			
C 141			
C 164			
C 181			
C 249			
C 251	-		
C 251 C 272			
C 251 C 272 C 317			
C 251 C 272 C 317 C 319			
C 251 C 272 C 317 C 319 C 360			
C 251 C 272 C 317 C 319 C 360 C 390			
C 251 C 272 C 317 C 319 C 360 C 390 C 71	F1G1H102A496	CAPACITOR, 50V, 1000pF	20
C 277			
--	--	---	----------------------------
0.004			
U 281			
C 283			
C 339			
C 344			
C 378			
C 379			
C 380			
C 419			
C 420			
C 616			
C 623			
C 637			
C 638			
C 659			
C 666			
C 677			
C 684			
C 72	EEEC YOD331P		Ω
C 73			0
C 80			
C 81			
C 83			
C 650			
	E40444744040		
	F 1G 1A474AU18	CAPACITOR, IUV, U.4/µF	/
C 09			
0.91			
1. 45			
0.00			
C 94			
C 94 C 95	F100/00/100/		
C 94 C 95 C 92	F1G0J224A001	CAPACITOR, 6.3V, 0.22µF	2
C 94 C 95 C 92 C 105	F1G0J224A001	CAPACITOR, 6.3V, 0.22µF	2
C 94 C 95 C 92 C 105 C 101	F1G0J224A001 EEFCD0D101ER	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF	2
C 94 C 95 C 92 C 105 C 101 C 653	F1G0J224A001 EEFCD0D101ER	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF	2
C 94 C 95 C 92 C 105 C 101 C 653 C 671	F1G0J224A001 EEFCD0D101ER	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF	2
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693	F1G0J224A001 EEFCD0D101ER	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF	2
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104	F1G0J224A001 EEFCD0D101ER EEFCX0D221R	САРАСІТОR, 6.3V, 0.22µF САРАСІТОR, 2V, 100µF САРАСІТОR, 2V, 220µF	2 4 1
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	САРАСІТОR, 6.3V, 0.22µF САРАСІТОR, 2V, 100µF САРАСІТОR, 2V, 220µF САРАСІТОR, 2V, 220µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110 C 113	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110 C 113 C 114	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	САРАСІТОR, 6.3V, 0.22µF САРАСІТОR, 2V, 100µF САРАСІТОR, 2V, 220µF САРАСІТОR, 10V, 1µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 104 C 110 C 113 C 114 C 119	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110 C 113 C 114 C 119 C 120	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 104 C 110 C 113 C 114 C 119 C 120 C 125	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	САРАСІТОR, 6.3V, 0.22µF САРАСІТОR, 2V, 100µF САРАСІТОR, 2V, 220µF САРАСІТОR, 10V, 1µF	2 4 4 2 2 2
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110 C 113 C 114 C 119 C 120 C 125 C 126	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 4 2 2 2
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 110 C 113 C 114 C 119 C 120 C 125 C 126 C 129	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 1 22
C 94 C 95 C 92 C 105 C 101 C 653 C 671 C 693 C 104 C 104 C 110 C 113 C 114 C 119 C 120 C 125 C 126 C 129 C 132	F1G0J224A001 EEFCD0D101ER EEFCX0D221R F1H1A1050015	CAPACITOR, 6.3V, 0.22µF CAPACITOR, 2V, 100µF CAPACITOR, 2V, 220µF CAPACITOR, 10V, 1µF	2 4 1 22

C 152			
C 153			
C 154			
C 155			
C 188			
C 194			
C 195			
C 244			
C 603			
C 640			
C 698			
C 799			
C 136	F1G1H3R3A543	CAPACITOR, 50V, 3.3pF	2
C 137			
C 142	F1G1H150A542	CAPACITOR, 50V, 15pF	3
C 143			
C 398			
C 172	F1G1H270A451	CAPACITOR, 50V, 27pF	2
C 173			
C 183	F1G1H1010005	CAPACITOR, 50V, 100pF	10
C 279			
C 387			
C 612			
C 641			
C 642			
C 643			
C 657			
C 668			
C 686			
C 186	F1G1H5R0A452	CAPACITOR, 50V, 5pF	2
C 189			
C 257	EEFUD0J151ER	CAPACITOR, 6.3V, 150µF	2
C 258			
C 294	F1G1H221A495	CAPACITOR, 50V, 220pF	12
C 295			
C 297			
C 298			
C 618			
C 619			
C 625			
C 661			
C 662			
C 674			
C 679			
C 680			
C 323	F1G1H6R0A452	CAPACITOR, 50V, 6pF	2
C 325			
C 327	F1L3D102A003	CAPACITOR, 2000V, 1000pF	1
C 337	F1H1H104A748	CAPACITOR, 50V, 0.1µF	17
C 606			

C 613 C 615 C 622 C 655 C 658 C 665 C 673 C 675 C 676 C 683 C 694 C 695 C 697 C 699 C 700			
C 355	F1J1E105A009	CAPACITOR, 25V, 1µF	5
C 356			
C 358			
C 359			
C 604			
C 374	F1G1C473A004	CAPACITOR, 16V, 0.047µF	4
C 632			
C 633			
C 634			
C 376	F1G1A683A014	CAPACITOR, 10V, 0.068µF	1
C 411	F1G1H100A544	CAPACITOR, 50V, 10pF	2
C 412			
C 608	EEFCX0J101R	CAPACITOR, 6.3V, 100µF	2
C 609			
C 611	F1L1E106A017	CAPACITOR, 25V, 10µF	9
C 626			
C 648			
C 649			
C 654			
C 669			
C 672			
C 687			
C 701			
C 614	F1H1H103A748	CAPACITOR, 50V, 0.01µF	2
C 624			
C 617	F1G1H220A542	CAPACITOR, 50V, 22pF	6
C 620			
C 660			
C 663			
C 678			
C 681			
C 621	F1J0J475A009	CAPACITOR, 6.3V, 4.7µF	4
C 646			
C 664			
C 682			

C 627	EEFCX0G151R	CAPACITOR, 4V, 150µF	1
C 639	F1G1H471A496	CAPACITOR, 50V, 470pF	1
C 644	F1G1H681A496	CAPACITOR, 50V, 680pF	1
C 645	F1J1E334A081	CAPACITOR, 25V, 0.33µF	1
C 656	F1H1H182A748	CAPACITOR, 50V, 1800pF	2
C 667			
C 670	EEFCD0G101ER	CAPACITOR, 4V, 100µF	1
C 685	F1H1E472A050	CAPACITOR, 25V, 4700pF	1
C 696	F1G1H152A496	CAPACITOR, 50V, 1500pF	1
C 702	F1K1E1060001	CAPACITOR, 25V, 10µF	2
C 703			
C 704	EEFCD0J470ER	CAPACITOR, 6.3V, 47µF	1
CF 1	D4CC1103A038	THERMISTOR	2
CF 6			
CN 6	K1FB104B0055	CONNECTOR	2
CN 7			
CN 2	K1MML0B00004	CONNECTOR	1
CN 3	K1KA02BA0014	CONNECTOR	1
CN 4	K1NAF0D00003	CONNECTOR	1
CN 5	K1KB50BA0001	CONNECTOR	1
N 8	K1KA20AA0261	CONNECTOR	1
CN 9	K1MN24BA0059	CONNECTOR	1
CN 11	K1MMC4B00013	CONNECTOR	1
CN 12	K1KA08AA0266	CONNECTOR	1
CN 14	K1KA02B00247	CONNECTOR	1
CN 15	K1KA10B00213	CONNECTOR	1
CN 16	K1MN50AA0018	CONNECTOR	1
CN 17	K1KA11AA0267	CONNECTOR	1
CN 18	K1MN26AA0074	CONNECTOR	1
CN 20	K1MY04AA0041	CONNECTOR	1
CN 21	K1MN12AA0018	CONNECTOR	1
CN 23	K1MN13AA0018	CONNECTOR	1
CN 24	K1KB30A00171	CONNECTOR	1
CN 25	K1KAA0A00143	CONNECTOR	1
CN 27	K1MY40BA0098	CONNECTOR	1
CN 30	K1MN06AA0058	CONNECTOR	1
CN 37	K1KA02AA0229	CONNECTOR	1
CN 35	K1MN10AA0018	CONNECTOR	1
D 1	MA2J72900L	DIODE	4
D 2			
D 3			
D 11			
D 4	B0JDBE000002	DIODE	3
D 6			
D 625			
D 7	MA3.114700I	DIODE	3
 D 8			
 D 9			
D 10	B0.ICPD000023	DIODE	3
	20001 2000020	5.002	5

D 799			
D 12	B0KB00000044	DIODE	2
D 13			
D 601	B0ADDH000004	DIODE	3
D 602			
D 603			
D 604	MAZ81200ML	DIODE	1
D 605	MAZ81800ML	DIODE	1
D 606	MA3S132E0L	DIODE	2
D 622			
D 608	B0JCQD000001	DIODE	1
D 609	B0JCMD000014	DIODE	7
D 611			
D 626			
D 628			
D 629			
D 631			
D 632			
D 610	B0JDAE000004	DIODE	3
D 627			
D 630			
D 612	MAZ80510ML	DIODE	6
D 613			
D 614			
D 615			
D 617			
D 618			
D 616	MAZ80620ML	DIODE	1
D 619	MA2S111-TX	DIODE	2
D 621			
D 620	B2ABAM000002	DIODE	1
D 623	B0JCCE000008	DIODE	1
D 624	DEDRB081L20	DIODE	1
F 1	K5H502Z00003	FUSE, 5A	1
F 2 🛆	K5H202Z00005	FUSE, 2A	4
F 3			
F 4			
F 6			
IC 1	C2GBC0000263	IC, CPU	1
IC 2	C1DB00001476	IC, CHIP SET	1
IC 3	C1DB00001359	IC, CHIP SET	1
IC 4	C0JBZZ000327	IC, THERMAL SENSOR	1
IC 9	C0JBAZ002423	IC, CLOCK GENERATOR	1
IC 10	C0DBZHG00043	IC, USB POWER CONTROL	2
IC 13			
IC 11	C1DB00001182	IC, LAN CONTROLLER	1
IC 12	C3EBCG000100	IC, EEPROM	1
IC 14	C1DB00001159	IC, PERIPHERAL LSI	1
IC 15	C0EBE0000460	IC	3
	· · · · · · · · · · · · · · · · · · ·	•	-

C 18	C2CBJA000003	IC, MICON	1
IC 19	C0CBCBC00137	IC, REGURATOR	1
IC 20	C0JBAA000347	IC, 1 GATE LOGIC	5
IC 33			
IC 39			
IC 44			
IC 650			
IC 21	C0JBAS000215	IC, GATE LOGIC	1
IC 23	DA2205IDBLET	IC, BIPOLAR LOGIC	1
IC 24	C0JBAS000218	IC, LOGIC	3
IC 28			
IC 29			
IC 26	C0ZBZ0000978	IC	1
IC 27	C0JBAB000619	IC, GATE LOGIC	1
IC 30	C3FBLC000040	IC, FLASH MEMORY	1
IC 31	C1CB00002268	IC, SECURITY CHIP	1
IC 32	C0JBAC000338	IC, GATE LOGIC	2
IC 37			
IC 34	C0JBAA000348	IC, 1 GATE LOGIC	2
IC 36			
IC 35	C0JBAE000306	IC,	2
IC 41			
IC 38	C0JBAC000339	IC,	1
IC 42	C1DB00001179	IC, LSI	1
IC 43	C0EBH0000457	IC	1
IC 46	C0JBAA000362	IC, LOGIC	1
IC 60	C3ABSG000029	IC, DDR2 SDRAM	8
IC 61			
IC 62			
IC 63			
IC 64			
IC 65			
IC 66			
IC 67			
IC 600	C0ABZA000047	IC, AMP	1
IC 601	C0ABBA000093	IC, OP AMP	1
IC 602	C0DBAFH00029	IC	1
IC 603	C0JBAD000182	IC, LOGIC	1
IC 604	C0JBAB000622	IC, 1 GATE LOGIC	1
IC 605	C0DBEFH00002	IC, REGURATOR	1
IC 607	C0EBE0000333	IC	1
IC 608	C0DBDJH00009	IC, LINEAR	1
IC 610	C0DBALH00003	IC	3
IC 611			
IC 612			
L 1	G1C100Z00013	INDUCTOR	2
L 2			
1 3	G1C1R0700002	INDUCTOR	5
			5

L 7			
L 8			
L 6	G1C91NM00001	INDUCTOR	1
L 9	J0JJC0000015	INDUCTOR	1
L 10	J0MAB0000116	INDUCTOR	4
L 11			
L 25			
L 26			
L 12	J0JHC0000074	INDUCTOR	4
L 13			
L 14			
L 15			
L 16	J0MAB0000169	INDUCTOR	2
L 17			
L 18	J0JDC0000045	INDUCTOR	5
L 21			
L 22			
L 27			
L 28			
L 600	DDAZS100MT3T	INDUCTOR	1
L 601	G1C100MA0106	INDUCTOR	1
L 602	G1C1R6Z00001	INDUCTOR	1
L 603	G1C4R7MA0106	INDUCTOR	2
L 605			
L 604	G1C220MA0077	INDUCTOR	1
L 606	G1C4R7MA0022	INDUCTOR	1
L 607	G1A160H00001	INDUCTOR	1
PA 1	K5J1AB000001	POLY SW	1
Q 1	UNR9214J0L	TRANSISTOR	12
Q 4			
Q 5			
Q 11			
Q 15			
Q 35			
Q 611			
Q 627			
Q 636			
Q 641			
Q 642			
Q 643			
Q 2	B1DHDC000028	TRANSISTOR	11
Q 3			
Q 8			
Q 14			
Q 16			
Q 19			
Q 22			
Q 24			

Q 31 O 625			
) 6	R1MRRC 400003	TRANSISTOR	Δ
07	B IMBBOA00003		-
09			
Q 9 O 10			
0 12	B1CEEB000001	TRANSISTOR	2
Q 12 Q 13		TRANSISTOR	2
Q 17	XP0421300L	TRANSISTOR	10
Q 21			-
Q 25			
Q 612			
Q 617			
Q 618			
Q 619			
Q 621			
Q 623			
Q 626			
Q 23	B1DHFD000015	TRANSISTOR	2
Q 604			
Q 28	UNR9213J0L	TRANSISTOR	6
Q 29			
Q 30			
Q 34			
Q 607			
Q 620			
Q 32	XP0411300L	TRANSISTOR	2
Q 33			
Q 600	XP0421400L	TRANSISTOR	3
Q 601			
Q 602			
Q 603	B1CHRD000001	TRANSISTOR	2
Q 606			
Q 608	B1CFGD000003	TRANSISTOR	3
Q 634			
Q 638			
Q 609	B1MBEDA00017	TRANSISTOR	4
Q 610			
Q 633			
Q 635			
Q 613	DETA144EETL	TRANSISTOR	1
Q 614	B1DHFB000003	TRANSISTOR	3
Q 616			
Q 622			
Q 615	B1DBGD000006	TRANSISTOR	4
Q 631			
Q 639			
Q 640			
Q 628	B1CFGD000004	TRANSISTOR	3
0.000			

0 629	XP0450100L	TRANSISTOR	1
) 632	B1DEGD000032	TRANSISTOR	1
) 637	B1MBEDA00018	TRANSISTOR	1
) 645	B1MBEDA00008	TRANSISTOR	1
2 0-0		PESISTOR 1/16W 6800	2
258			2
x 200		RESISTOR 1/16W 27 40	2
N 2 D 15		RESISTOR, 1/10W, 27.402	5
N 15 D 16			
		DESISTOR 1/16W 54 00	5
× 4 > 17	ERJ2RRF34R9A	RESISTOR, 1/10W, 54.912	5
N 17			
X 10 2 25			
<u> </u>			
<u> </u>	ERJ2RKF39R2X	RESISTOR, 1/16W, 39.2Ω	1
	EKJ2GEJ151X		1
K 11	EKJ3GEY0R00V	RESISTOR, $1/16W$, 0Ω	3
R 437			
R 438			
R 12	ERJ2RKF2000X	RESISTOR, $1/16W$, 200Ω	2
R 43			
R 13	ERJ2GEJ560X	RESISTOR, $1/16W$, 56Ω	6
R 14			
R 27			
R 29			
R 31			
R 32			
R 23	ERJ3GEYJ100V	RESISTOR, 1/16W, 10Ω	5
R 636			
R 690			
R 712			
R 731			
R 24	ERJ2RKF1001X	RESISTOR, 1/16W, 1KΩ	2
R 732			
R 25	ERJ2RKF2001X	RESISTOR, 1/16W, 2KΩ	1
R 26	ERJ2GEJ562X	RESISTOR, 1/16W, 5.6KΩ	6
R 348			
R 609			
R 612			
R 613			
R 749			
R 28	ERJ2GEJ750X	RESISTOR, 1/16W, 75Ω	1
R 33	ERJ2RKF2210X	RESISTOR, 1/16W, 221Ω	2
R 39			
R 34	ERJ2RKF1000X	RESISTOR, 1/16W, 100Ω	3
R 40			
R 42			
R 37	ERJ2RKF24R9X	RESISTOR, 1/16W, 24.9Ω	4
R 38		ALGIGTOR, 1/1000, 24.92	4

R 62			
R 231			
R 41	ERJ2GE0R00X	RESISTOR, 1/16W, 0Ω	60
R 110			
R 111			
R 112			
R 113			
R 114			
R 115			
R 116			
R 117			
R 118			
R 119			
R 120			
R 121			
R 122			
R 123			
R 124			
R 125			
R 126			
R 127			
R 128			
R 129			
R 130			
R 131			
R 131			
D 132			
R 133			
D 135			
R 133			
R 145			
R 159			
R 223			
R 220			
R 234			
R 235			
R 245			
R 246			
R 311			
к 314			
R 322			
R 323			
R 324			
R 325			
R 332			
R 370			
R 371			
R 376			
R 393			
R 396			
R 410		1	

R 42/ R 423 R R 4243 R R 4263 R R 427 ERJ2RKF80R6X R 703 R R 447 ERJ2RKF80R6X R 188 R R 189 ERJ2RKF80R6X R 189 ERJ2REF R 189 ERJ2REF R 189 ERJ2REF R 189 ERJ2REF R 219 ERJ2REF R 221 ERJ2REF R 222 F R 224 F R 242<	5.40-	1	1	1
R 443 R 443 R 443 R 445 R 445 R 476 R 404 R 475 R 604 R 476 R 700 R 100 R 702 R 100 R 703 R 100 R 47 ERJ2RKF80R6X R 48 R 145 R 48 R 145 R 145 R 145 R 148 R 145 R 148 R 145 R 148 R 149 R 149 ERJ2GEJ103X R 189 R 145 R 189 R 145 R 189 R 149 R 221 R 242 R 222 R 242 R 242 R 247 R 242 R 247 R 303 R 304 R 304 R 304 R 305 R 304 R 306 R 304 R 307 R 304 R 308 R 304	R 427			
R 443 R 465 R R 445 R R 465 R R 700 R R 700 R R 702 R R 703 R R 706 R R 7072 R R 703 R R 706 R R 707 ERJ2RKF80R8X R 848 R R 49 ERJ2GEJ103X R 188 R R 188 R R 188 R R 189 R R 219 R R 221 R R 222 R R 224 R R 229 R R 242 R R 242 R R 300 R R 301 R R 302 R R 303 R R 304 R R 305 R R 306 R R 307 R R 308 R R 308 R </td <td>R 428</td> <td></td> <td></td> <td></td>	R 428			
R 435 R 475 R 445 R 4475 R 604 Image: state stat	R 443			
R 470 R 604 R R 604 R R 604 R R 700 R 702 R R R 702 R R R R 706 R 2 R R 722 R R 2 R 44 ERJ2RKF80R6X RESISTOR, 1/16W, 80.60 2 R 48 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 188 R 188 R R 188 R 188 1 R 219 R 224 1 R 221 R 116W, 10KΩ 58 R 242 R 116W, 10KΩ 58 R 229 R 242 1 R 221 R 1 1 R 222 R 1 1 1 R 242 R 1 1 1 R 303 R 1 1 1 R 303 R 1 1 1 R 303 R 1 1 1 R 306 1 <td>R 455</td> <td></td> <td></td> <td></td>	R 455			
R 604 F 604 F 700 F 700 R 700 R 702 F 703 F 705 R 706 F 772 F 753 F 753 R 47 ERJ2RKF80R8X RESISTOR, 1/16W, 80.60 2 R 48 F 753 F 753 F 753 R 49 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145 F 188 F 189 F 189 R 196 F 129 F 145 F 145 R 221 R 221 F 229 F 244 R 221 F 244 F 247 F 242 R 242 F 247 F 242 F 247 R 224 F 247 F 247 F 247 R 247 F 247 F 247 F 247 R 242 F 247 F 247 F 247 R 242 F 247 F 247 F 247 R 242 F 247 F 247 F 247 R 247 F 247 F 247 F 247 R 247 F 247 F 247 F 247	R 4/5			
R 700 R 702 R 703 R 703 R 703 R 703 R 703 R 705 R 705 R 722 R 753 2 R 753 ERJ2RKF80R8X RESISTOR, 1/16W, 80.6Ω 2 R 46 P P 2 R 47 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 185 R 189 1 1 R 188 R 189 1 1 R 219 R 241 1 1 R 221 R 242 1 1 R 222 R 233 1 1 1 R 242 R 242 1 1 1 1 R 242 R 241 1	R 604			
R 702 R 703 R R 706 R 722 R 706 R 753 R 47 ERJ2RKF80R6X RESISTOR, 1/16W, 80.6Ω 2 R 44 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145 F 148 58 R 145 F 148 58 R 188 F 145 58 R 189 F 146 58 R 196 F 116W, 80.6Ω 58 R 219 F 116W, 80.6Ω 58 R 220 F 1 1 1 R 306 F 1 1 1 R 306 F 1 1 1 1 R 307 R 360 1 1 1	R 700			
R 703 R 705 R 705 R 705 R 705 2 R 773 ERJ2RKF80R6X RESISTOR, 1/16W, 80.6Ω 2 R 48 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145 F145 F145 58 R 189 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 189 F146 F146 F146 R 189 F145 F146 F146 R 199 F141 F146 F146 R 219 F142 F146 F146 R 221 F142 F146 F146 R 222 F214 F229 F142 R 229 F242 F242 F242 R 242 F242 F242 F242 R 247 F243 F146 F146 R 300 F300 F147 F148 R 306 F309 F147 F147 R 306 F300 F147 F147 R 307 F388 F147 F147 R 306 F147 F1411 F1411 <tr< td=""><td>R 702</td><td></td><td></td><td></td></tr<>	R 702			
R 706 R F <td>R 703</td> <td></td> <td></td> <td></td>	R 703			
R 722 R F F R 47 ERJ2RKF80R6X RESISTOR, 1/16W, 80.6Ω 2 R 48 F F 68 R 49 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 188 F 189 F R 196 F F 116W, 10KΩ 58 R 188 F 189 F 116W, 10KΩ 58 R 219 F F 116W, 10KΩ 58 58 R 221 F F F 116W, 10KΩ 58 R 2219 F F F F 116W, 10KΩ 58 R 2210 F F F F 116W, 10KΩ 58 R 2219 F F F F 116W, 10KΩ 11	R 706			
R 753 ERJ2RKF80R6X RESISTOR, 1/16W, 80.6Ω 2 R 48 2 R 48 58 58 58 58 58 58 58 1060 58 <	R 722			
R 47 ERJ2RKF80R6X RESISTOR, 1/16W, 80.6Ω 2 R 48 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145 F 58 R 188 F 58 R 196 F F R 219 F F R 224 F F R 229 F F R 242 F F R 243 F F R 300 F F R 301 F F R 302 F F R 304 F F R 305 F F R 306 F F R 376 F F R 386 F F	R 753			
R 48 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145 F 58 58 R 188 F 199 58 R 199 F 58 58 R 188 F 199 58 R 199 F 58 58 R 199 F 58 58 R 199 F 58 58 R 196 F 58 58 R 219 F 58 58 R 221 F 58 58 R 222 F 58 58 R 242 F 58 58 R 247 F 58 58 R 300 F 58 58 R 306 F 58 58 R 376 F 58 58	R 47	ERJ2RKF80R6X	RESISTOR, 1/16W, 80.6Ω	2
R 49 ERJ2GEJ103X RESISTOR, 1/16W, 10KΩ 58 R 145	R 48			
R 145 R 188 R 196 R 219 R 221 R 224 R 229 R 242 R 247 R 2483 R 292 R 303 R 300 R 306 R 307 R 308 R 377 R 377 R 370 R 370 R 370 R 370 R 387 R 388 R 411 R 412 R 436 R 457	R 49	ERJ2GEJ103X	RESISTOR, 1/16W, 10KΩ	58
R 188 8 R 189 8 R 196 8 R 219 9 R 224 9 R 242 9 R 242 9 R 247 9 R 283 9 R 292 9 R 293 9 R 300 9 R 303 9 R 304 9 R 305 9 R 307 9 R 372 9 R 380 9 R 388 9 R 388 9 R 431 9 R 435 9 R 458 9	R 145			
R 199 R 196 R 219 R 224 R 247 R 247 R 247 R 247 R 292 R 303 R 300 R 303 R 303 R 304 R 309 R 309 R 310 R 320 R 347 R 365 R 372 R 378 R 378 R 380 R 388 R 411 R 411 R 411 R 412 R 436 R 457	R 188			
R 196 R 219 R 221 R 224 R 229 R 242 R 243 R 244 R 245 R 247 R 248 R 249 R 241 R 242 R 242 R 243 R 244 R 245 R 247 R 248 R 249 R 249 R 300 R 304 R 305 R 306 R 347 R 365 R 379 R 365 R 379 R 380 R 386 R 386 R 402 R 411 R 411 R 411 R 411 R 411 R 411 R 436 R 436 R 436 R 436 R 436 R 436 R 457	R 189			
R 219 R 221 R 224 R 242 R 247 R 248 R 247 R 247 R 243 R 2447 R 242 R 247 R 283 R 293 R 300 R 300 R 303 R 306 R 306 R 307 R 376 R 377 R 376 R 377 R 378 R 379 R 380 R 388 R 411 R 411 R 411 R 431 R 435	R 196			
R 221 R 224 R 242 R 247 R 247 R 247 R 283 R 292 R 300 R 300 R 300 R 300 R 306 R 306 R 306 R 307 R 365 R 378 R 379 R 380 R 388 R 411 R 412 R 436 R 436 R 436 R 457 R 458	R 219			
R 224 R 229 R 242 R 242 R 247 R 247 R 247 R 247 R 247 R 247 R 248 R 247 R 247 R 247 R 247 R 247 R 248 R 300 R 300 R 306 R 309 R 310 R 347 R 347 R 347 R 347 R 346 R 378 R 379 R 388 R 402 R 411 R 412 R 431 R 436 R 436 R 436 R 436 R 457 R 458	R 221			
R 229 R R 242	R 224			
R 242 R R 247	R 229			
R 247 R 283 R 292 R 293 R 300 R 300 R 303 R 304 R 306 R 307 R 308 R 378 R 379 R 380 R 387 R 388 R 411 R 412 R 436 R 457 R 458	R 242			
R 283 R 292 R 293 R 300 R 303 R 303 R 304 R 306 R 306 R 307 R 310 R 320 R 347 R 365 R 372 R 378 R 379 R 380 R 387 R 388 R 411 R 411 R 433 R 436 R 436 R 436 R 457	R 247			
R 292 R 293 R 300 R 303 R 304 R 306 R 309 R 310 R 320 R 347 R 365 R 372 R 378 R 379 R 380 R 387 R 388 R 411 R 411 R 436 R 438	R 283			
R 293 Image: Constraint of the second of	R 292			
R 300 R R 303 R R 304 R R 306 R R 309 R R 310 R R 320 R R 347 R R 365 R R 372 R R 378 R R 380 R R 387 R R 388 R R 402 R R 411 R R 412 R R 436 R R 436 R R 436 R R 438 R R 458 R	R 293			
R 303 R R 304 R R 306 R R 309 R R 310 R R 320 R R 347 R R 365 R R 372 R R 378 R R 379 R R 380 R R 388 R R 402 R R 411 R R 431 R R 436 R R 457 R R 458 R	R 300			
R 304 R 306 R 309 R 310 R 310 R 310 R 320 R 320 R 347 R 365 R 372 R 378 R 379 R 380 R 387 R 388 R 402 R 411 R 412 R 436 R 436 R 438	R 303			
R 306 R R 309 R R 310 R R 320 R R 321 R R 347 R R 365 R R 372 R R 378 R R 379 R R 380 R R 387 R R 388 R R 402 R R 411 R R 412 R R 436 R R 436 R R 457 R R 458 R	R 304			
R 309 R 310 R 320 R 347 R 347 R 365 R 372 R 378 R 379 R 380 R 388 R 402 R 411 R 412 R 431 R 436 R 457 R 458	R 306			
R 310 Image: Stress	R 309			
R 320 Image: Second	R 310			
R 347 Image: Second	R 320			
R 365 R 372 R 378 R 379 R 380 R 387 R 388 R 402 R 411 R 412 R 411 R 412 R 431 R 436 R 457 R 458	R 347			
R 372 R 378 R 379 R 380 R 387 R 388 R 402 R 411 R 412 R 431 R 436 R 436 R 457 R 458	R 365			
R 378 R 379 R 380 R 387 R 388 R 402 R 411 R 412 R 413 R 431 R 436 R 457 R 458	R 372			
R 379 R 380 R 387 R 388 R 402 R 411 R 412 R 431 R 436 R 437 R 458	R 378			
R 380 R 387 R 388 R 402 R 411 R 412 R 431 R 436 R 436 R 457 R 458	R 379			
R 387 R 387 R 388 R 402 R 411 R 412 R 431 R 436 R 436 R 457 R 458	R 380			
R 388 R 402 R 411 R 412 R 431 R 436 R 457 R 458	R 387			
R 402 R 411 R 412 R 431 R 436 R 457 R 458	R 388			
R 411 R 412 R 431 R 436 R 436 R 457 R 458	R 402			
R 412 R 431 R 436 R 457 R 458	R 411			
R 431 R 436 R 457 R 458	R 412			
R 436 R 457 R 458	R 431			
R 450 R 458	D 436			
R 458	P 457			
	11 400	I	I I	I

R 461 R 462 R 464 R 467 R 469 R 471 R 472 R 615 R 635 R 635 R 640 R 641 R 641 R 677 R 707 R 711 R 715 R 716 R 716 R 721 R 730 R 735 R 736 R 741 R 745			
R 50	ERJ2GEJ222X	RESISTOR. 1/16W. 2.2KΩ	4
R 51			
R 294			
R 295			
R 52	FRJ2GFJ101X	RESISTOR 1/16W 1000	24
R 202			
R 225			
R 227			
R 241			
P 307			
R 330			
R 331			
R 344			
R 354			
R 397			
R 398			
R 399			
R 429			
R 430			
R 602			
R 603			
R 657			
R 658			
R 659			
R 662			
R 663			
R 664			
R 665			

R 53	ERJ2RKF1002X	RESISTOR, 1/16W, 10KΩ	3
R 401			
R 643			
R 57	D1H82224A024	RESISTOR ARRAY	1
R 58	ERJ2RKF1501X	RESISTOR, 1/16W, 1.5KΩ	1
R 59	ERJ2GEJ390X	RESISTOR, 1/16W, 39Ω	2
R 60			
R 61	ERJ2RKF2550X	RESISTOR, 1/16W, 255Ω	1
R 63	ERJ2GEJ100X	RESISTOR, 1/16W, 10Ω	17
R 315			
R 316			
R 632			
R 633			
R 645			
R 646			
R 675			
R 676			
R 708			
R 709			
R 719			
R 720			
R 727			
R 728			
R 739			
R 740			
R 64	ERJ2GEJ201X	RESISTOR, 1/16W, 200Ω	4
R 66			
R 68			
R 70			
R 76	D1HG2208A001	RESISTOR ARRAY	8
R 77			
R 78			
R 79			
R 104			
R 105			
R 106			
R 107			
R 80	ERJ2GEJ220X	RESISTOR. 1/16W. 22Ω	24
R 81			
R 82			
R 83			
R 84			
R 85			
R 86			
R 87			
R 88			
R 89			
R 90			
R 91			
R 92			
17.92	I	I	

R 93			
R 94			
R 95			
R 96			
R 97			
R 98			
R 99			
R 100			
R 101			
R 102			
B 103			
R 108	D1HA56080001	RESISTOR ARRAY	7
R 109			
R 136			
R 137			
R 138			
R 139			
R 140			
R 147	FR.12GE.1102X	RESISTOR 1/16W 1KO	15
R 148			10
R 166			
R 169			
P 273			
R 273			
R 200			
R 321			
R 335			
R 300			
R 381			
R 382			
R 451			
R 459			
R 460			
R 686			
R 149	ERJ2GEJ2R2X	RESISTOR, 1/16W, 2.2 Ω	2
R 173			40
K 150	EKJZKKF49K9X	KESISIUK, 1/16W, 49.90	16
K 151			
K 152			
K 153			
K 154			
R 155			
R 192			
R 193			
R 194			
R 195			
R 349			
R 350			
R 351			
R 352			
R 446			

R 447			
R 163 EI	RJ2GEJ330X	RESISTOR, 1/16W, 33Ω	27
R 164			
R 165			
R 175			
R 176			
R 177			
R 178			
R 179			
R 180			
R 182			
R 183			
R 184			
R 185			
R 186			
R 187			
R 190			
R 191			
R 218			
R 269			
R 270			
R 271			
R 272			
R 274			
R 275			
R 373			
R 374			
R 474			
R 167 D	1H83304A024	RESISTOR ARRAY	1
R 172 EI	RJ2RKF4750X	RESISTOR, 1/16W, 475Ω	1
R 174 EI	RJ2GEJ1R0X	RESISTOR, 1/16W, 1Ω	2
R 248			_
R 198 D	1H81034A024	RESISTOR ARRAY	9
R 217			-
R 220			
R 222			
B 262			
R 407			
R 408			
R 452			
R 463			
R 216	RJ2GEJ104X	RESISTOR. 1/16W. 100KΩ	27
R 276			
R 277			
R 278			
R 279			
R 282			
D 206			
N 290			
D 201			
r 301			

R 302			
R 308			
R 313			
R 334			
R 336			
R 340			
P 343			
R 343			
R 302			
R 304			
R 617			
R 619			
R 620			
R 621			
R 650			
R 651			
R 654			
R 656			
R 661			
R 230	ERJ2RKF22R6X	RESISTOR, 1/16W, 22.6Ω	1
R 232	DEARA8AJ103M	RESISTOR ARRAY	16
R 259			
R 260			
R 261			
R 369			
R 383			
R 384			
D 385			
R 303			
R 300			
R 389			
R 390			
R 391			
R 403			
R 404			
R 405			
R 406			
R 233	ERJ2GEJ472X	RESISTOR, 1/16W, 4.7KΩ	3
R 699			
R 757			
R 236	ERJ2GEJ203X	RESISTOR, 1/16W, 20KΩ	1
R 237	ERJ2GEJ106X	RESISTOR, 1/16W, 10MΩ	1
R 238	ERJ2GEJ105X	RESISTOR, 1/16W, 1MΩ	8
R 353			
R 618			
R 649			
R 652			
R 660			
R 689			
P 604			
D 240		DESISTOR 1/16W/ 1200	2
R 249	ERJ2GEJ121X	REDIDIOK, 1/1000, 12002	2
R 250			

R 266	ERJ2GEJ473X	RESISTOR, 1/16W, 47KΩ	8
R 267			
R 268			
R 449			
R 616			
R 630			
R 670			
R 698			
P 284		RESISTOR 1/16W 1800	1
D 205		RESISTOR, 1/16W, 1802	7
R 200	ERJZGEJZZIA	RESISTOR, 1/10W, 2200	'
R 280			
R 287			
R 288			
R 290			
R 291			
R 799			
R 289	ERJ2GEJ471X	RESISTOR, 1/16W, 470Ω	1
R 338	ERJ2GEJ334X	RESISTOR, 1/16W, 330KΩ	1
R 346	ERJ2RHD562X	RESISTOR, 1/16W, 5.6KΩ	1
R 355	EXBV8V750JV	RESISTOR ARRAY	1
R 356	ERJ2GEJ223X	RESISTOR, 1/16W, 22KΩ	5
R 357			
R 358			
R 359			
R 666			
R 367	D1H81024A024	RESISTOR ARRAY	2
R 368			
R 395	ERJ2RKF5602X	RESISTOR, 1/16W, 56KΩ	1
R 400	ERJ2RKF3901X	RESISTOR, 1/16W, 3.9KΩ	1
R 423	ERJ2GEJ153X	RESISTOR, 1/16W, 15KΩ	4
R 634			
R 710			
R 729			
R 601	D17700000046	RESISTOR 1W 5m0	2
R 701	21220000010		-
R 605		RESISTOR 1/16W 10KO	2
P 608			2
R 606		RESISTOR 1/16W 100KO	5
P 611			5
R 030			
R 079			
R 688			
R 607	ERJ2RKF1503X	RESISTOR, $1/16W$, $150K\Omega$	3
R 610			
R 750			
R 614	ERJ3GEYJ3R3V	RESISTOR, 1/16W, 3.3Ω	1
R 622	D1BDR1000002	RESISTOR, 1/8W, 0.1Ω	2
R 623			
R 624	D1BDR2700001	RESISTOR, 1/8W, 0.27Ω	1
R 625	ERJ2RKF1102X	RESISTOR, 1/16W, 11KΩ	1

R 627	ERJ2RKF1302X	RESISTOR, 1/16W, 13KΩ	2
R 682			
R 628	D1BDR0220001	RESISTOR, 1/8W, 0.022Ω	6
R 629			
R 704			
R 705			
R 726			
R 743			
R 631	ERJ2GEJ474X	RESISTOR, 1/16W, 470KΩ	3
R 747			
R 797			
R 637	ERJ2RHD752X	RESISTOR, 1/16W, 7.5KΩ	1
R 639	ERJ2RKF2002X	RESISTOR, 1/16W, 20KΩ	2
R 733			
R 642	ERJ2RKF3002X	RESISTOR, 1/16W, 30KΩ	1
R 644	ERJ2RHD102X	RESISTOR, 1/16W, 1KΩ	1
R 647	D1BDR0330001	RESISTOR, 1/8W, 0.033Ω	6
R 648			
R 725			
R 742			
R 744			
R 758			
R 653	ERJ2GEJ684X	RESISTOR, 1/16W, 680KΩ	1
R 655	ERJ2GEJ225X	RESISTOR, 1/16W, 2.2MΩ	1
R 667	ERJ6GEYJ561V	RESISTOR, 1/10W, 560Ω	1
R 668	ERJ6GEYJ222V	RESISTOR, 1/10W, 2.2KΩ	2
R 669			
R 673	ERJ2RKF1004X	RESISTOR, 1/16W, 1MΩ	2
R 681			
R 674	ERJ2RHD223X	RESISTOR, 1/16W, 22KΩ	1
R 678	ERJ2RHD333X	RESISTOR, 1/16W, 33KΩ	1
R 680	ERJ2RKF5102X	RESISTOR, 1/16W, 51KΩ	3
R 693			
R 717			
R 684	ERJ2RHD123X	RESISTOR, 1/16W, 12KΩ	2
R 738			
R 685	ERJ2RHD222X	RESISTOR, 1/16W, 2.2KΩ	1
R 687	ERJ2RHD132X	RESISTOR, 1/16W, 1.3KΩ	1
R 691	ERJ2GEJ302X	RESISTOR, 1/16W, 3KΩ	1
R 692	ERJ2GEJ154X	RESISTOR, 1/16W, 150KΩ	2
R 695			
R 696	ERJ3GEYJ1R0V	RESISTOR, 1/16W, 1.0Ω	1
R 713	ERJ2RKF4701X	RESISTOR, 1/16W, 4.7KΩ	1
R 714	ERJ2RKF1502X	RESISTOR, 1/16W, 15KΩ	2
R 737			
R 718	ERJ2RKF2402X	RESISTOR, 1/16W, 24KΩ	2
R 734			
R 723	D1BDR0470002	RESISTOR, 1/8W, 0.047Ω	1
R 746	ERJ2RHD104X	RESISTOR, 1/16W, 100KΩ	1
R 748	ERJ2RHD3652X	RESISTOR, 1/16W, 36.5KΩ	1

R 751		RESISTOR 1/16W/ 3KO	2
R 752			2
R 754	ERA3YKB104V	RESISTOR 1/16W/ 100KO	2
R 755			-
R 756	ERA3YEB333V	RESISTOR, 1/16W, 33KQ	1
SW 1	K0D112A00096	SW	1
T 1	G5BYC0000010	TRANCE	1
X 1	H0J143500040	OSCILLATOR, 14.318MHz	1
X 2	H0J327200115	OSCILLATOR. 32.768KHz	1
X 4	H0J250500025	OSCILLATOR. 25MHz	1
X 5	H2D800400015	OSCILLATOR, 8MHz	1
C 900	F1G1H120A542	CAPACITOR, 50V, 12pF	1
C 901	F1G1H150A542	CAPACITOR, 50V, 15pF	1
C 902	F1G1C104A042	CAPACITOR, 16V, 0,1µF	7
C 905			
C 907			
C 909			
C 921			
C 923			
C 926			
C 903	F1J0J106A024	CAPACITOR, 6.3V, 10µF	4
C 914		, ,	
C 922			
C 924			
C 904	F1G1H102A496	CAPACITOR, 50V, 1000pF	4
C 908			
C 941			
C 942			
C 906	F1G1E103A062	CAPACITOR, 25V, 0.01µF	3
C 916			
C 918			
C 910	F1G0J224A001	CAPACITOR. 6.3V. 0.22µF	9
C 912			
C 915			
C 917			
C 925			
C 927			
C 928			
C 932			
C 934			
C 913	F1H1A1050015	CAPACITOR, 10V, 1µF	4
C 919			
C 920			
C 933			
C 929	F1G1H1010005	CAPACITOR, 50V, 100pF	2
C 935			
C 930	F1G1H471A496	CAPACITOR, 50V, 470pF	1
C 936	EEFCD0J470ER	CAPACITOR, 6.3V, 47µF	3
		, , r	

C 940			
C 937	F1H0J1050022	CAPACITOR, 6.3V, 1µF	1
CN 900	K1MN10BA0070	CONNECTOR	1
CN 901	K1MY40BA0098	CONNECTOR	1
D 900	B0JCMD000014	DIODE	1
IC 900	C1BB00000868	IC, AC97 CODEC	1
IC 901	C0CBCBC00130	IC, REGURATOR	1
IC 902	C1BB00000873	IC, AUDIO AMP	1
IC 903	C0ABBA000093	IC, OP AMP	1
JK 901	K2HC103B0197	ЈК	2
JK 902			
L 900	J0JDC0000045	INDUCTOR	2
L 901			
L 902	J0MAB0000174	INDUCTOR	2
L 903			
Q 900	UNR9211J0L	TRANSISTOR	1
Q 901	XP0421300L	TRANSISTOR	1
R 900	ERJ2GEJ220X	RESISTOR, 1/16W, 22Ω	2
R 901			
R 903	ERJ2GEJ101X	RESISTOR, 1/16W, 100Ω	1
R 905	ERJ2GEJ330X	RESISTOR, 1/16W, 33Ω	1
R 909	ERJ2GEJ103X	RESISTOR, 1/16W, 1KΩ	9
R 910			
R 915			
R 918			
R 926			
R 932			
R 933			
R 934			
R 936			
R 911	ERJ2GEJ473X	RESISTOR, 1/16W, 47KΩ	3
R 916			
R 925			
R 914	ERJ2GEJ472X	RESISTOR, 1/16W, 4.7KΩ	2
R 939			
R 919	ERJ2GEJ273X	RESISTOR, 1/16W, 27KΩ	3
R 920			
R 930			
R 921	ERJ2GEJ471X	RESISTOR, 1/16W, 470Ω	1
R 922	ERJ2GEJ222X	RESISTOR, 1/16W, 2.2KΩ	2
R 923			
R 924	ERJ2GEJ683X	RESISTOR, 1/16W, 68KΩ	1
R 927	ERJ2GEJ104X	RESISTOR, 1/16W, 100KΩ	2
R 931			
R 928	ERJ2RKF1002X	RESISTOR, 1/16W, 10KΩ	2
R 929			
R 935	ERJ2RKF223X	RESISTOR, 1/16W, 22KΩ	1
R 937	ERJ2GEJ102X	RESISTOR, 1/16W, 1KΩ	2
R 938			
R 940	D1H81034A024	RESISTOR, ARRAY	1

X 900	H0J245500044	OSCILLATOR, 24.576MHz	1
I/O PCB			
C 880	F1H1H104A748	CAPACITOR, 50V, 0.1µF	1
C 883	F1L1E106A017	CAPACITOR, 25V, 10µF	1
C 884	F1G1H330A542	CAPACITOR, 50V, 33pF	7
C 885			
C 886			
C 887			
C 888			
C 889			
C 890			
C 891	F1G1C104A042	CAPACITOR, 16V, 0,1µF	1
C 892	EZASCE101M	CAPACITOR ARRAY	2
C 893			
CN 880	K1MN24AA0018	CONNECTOR	1
CN 881	K1FA209BA004	CONNECTOR	1
CN 882	K1FB115BA014	CONNECTOR	1
CN 883	DEJS830YA	CONNECTOR	1
D 880	B0 ICPD00023	DIODE	1
D 881	MA2 1729001	DIODE	1
IK 880	K2E72B000046	R R R R R R R R R R R R R R R R R R R	1
JK 880			1
			7
	202000188	INDUCTOR	1
L 002			
L 003			
L 884			
L 885			
L 886			
L 887			
PA 880	K5J1BB000001	POLY SW	1
R 800	ERJ2RKF1102X	RESISTOR, 1/16W, 11KΩ	1
R 881	D1BDR4700001	RESISTOR, 1/8W, 0.47Ω	1
R 882	ERJ2RKF75R0X	RESISTOR, 1/16W, 75Ω	3
R 883			
R 884			
R 885	ERJ2GEJ222X	RESISTOR, 1/16W, 2.2KΩ	2
R 886			
PAD PCB			
C 800	F1G1H681A450	CAPACITOR, 50V, 680pF	2
C 801			
C 802	F1G1E103A062	CAPACITOR, 25V, 0.01µF	1
C 803	F1G1C104A042	CAPACITOR, 16V, 0.1µF	2
C 804			
C 805	F1J0J1060004	CAPACITOR, 6.3V, 10µF	1
CN 800	K1MY04BA0104	CONNECTOR	1
CN 801	K1MN08AA0068	CONNECTOR	1
CN 802	K1MN13AA0018	CONNECTOR	1
IC 800	C0EBH0000457	IC	1
IC 801	C1DB00001417	IC, FLAT PAD CONTROLLER	1
Q 800	B1GKCFJN0004	TRANSISTOR	2

Q 801			
R 800	ERJ2GEJ273X	RESISTOR, 1/16W, 27KΩ	1
R 801	ERJ2GEJ822X	RESISTOR, 1/16W, 8.2KΩ	2
R 802			
R 803	ERJ2GEJ105X	RESISTOR, 1/16W, 1MΩ	1
R 804	ERJ2GEJ103X	RESISTOR, 1/16W, 10KΩ	2
R 805			
RA 800	D1H81034A024	RESISTOR ARRAY	1
SW 800	K0ZZ00000618	SW	2
SW 801			
SW 802	EVQPLDA15	SW	2
SW 803			
X 800	H2D400400012	OSCILLATOR, 4MHz	1
SWITCH PCB			
CN 950	K1MN08AA0068	CONNECTOR	1
LD 951	B3ACB0000105	LED	1
R 951	ERJ2GEJ221X	RESISTOR, 1/16W, 220Ω	1
SW 950	EVQPLDA15	SW	6
SW 951			
SW 952			
SW 953			
SW 954			
SW 955			
LED PCB			
CN 841	K1MN10AA0058	CONNECTOR	1
LD 840	B3AGB0000040	LED	1
LD 841	B3ABB0000210	LED	5
LD 842			
LD 843			
LD 844			
LD 845			
LD 846	B3ADB0000065	LED	1
PORT PCB			
C 851	F1J1A1050021	CAPACITOR, 10V, 1µF	3
C 852			
C 854			
C 855	J0MAB0000146	INDUCTOR	3
C 856			
C 857			
CA 851	J0HABC000004	CAPACITOR ARRAY	6
CA 852			
CA 854			
CA 857			
CA 858			
CA 859			
CN 850	K1KBA0A00102	CONNECTOR	1
CN 851	K1KAA0AA0244	CONNECTOR	1
L 850	J0MAB0000116	INDUCTOR	1
L 852	DDB5Z031J-L	INDUCTOR	2
L 853			

TS PS2 PCB			
C 900	F1G1C104A042	CAPACITOR, 16V, 0.1µF	4
C 907			
C 908			
C 909			
C 901	F1G1E472A062	CAPACITOR, 25V, 4700pF	3
C 905			
C 913			
C 902	F1G1E103A062	CAPACITOR, 25V, 0.01µF	1
C 903	F1G1H681A450	CAPACITOR, 50V, 680pF	2
C 906			
C 910	F1G1H560A451	CAPACITOR, 50V, 56pF	2
C 912			
C 911	F1J1A1050021	CAPACITOR, 10V, 1µF	1
CN 900	K1MN04B00073	CONNECTOR	1
CN 901	K1KA07BA0014	CONNECTOR	1
IC 900	C0EBH0000457	IC	1
IC 901	C1DB00001351	IC	1
Q 900	XP0431200L	TRANSISTOR	2
Q 902			
Q 901	UNR9113J0L	TRANSISTOR	1
R 900	ERJ2GEJ102X	RESISTOR, 1/16W, 1KΩ	2
R 903			
R 901	ERJ2GEJ822X	RESISTOR, 1/16W, 8.2KΩ	2
R 904			
R 902	ERJ2GEJ303X	RESISTOR, 1/16W, 30KΩ	1
R 905	ERJ2GE0R00X	RESISTOR, 1/16W, 0Ω	2
R 906			
R 908	ERJ2GEJ103X	RESISTOR, 1/16W, 10KΩ	2
R 909			
X 900	H2D100500002	OSCILLATOR, 10MHz	1
SD PCB			
C 891	F1G1H330A451	CAPACITOR, 50V, 33pF	1
CN 890	K1NA09E00076	CONNECTOR	1
CN 891	K1MN12BA0059	CONNECTOR	1
D 890	B3ACB0000020	DIODE	1
Q 890	UNR9113J0L	TRANSISTOR	1
R 890	ERJ6GEYJ101V	RESISTOR, 1/10W, 100Ω	1
R 891	ERJ2GE0R00X	RESISTOR, 1/16W, 0Ω	1
R 892	ERJ2GEJ103X	RESISTOR, 1/16W, 1KΩ	1